

Dimensional Drawings




Fig. 1 Dimensional drawing of light source and receiver, dimensions in mm




Fig. 2 Dimensional drawing of light source and receiver with mounting rail, dimensions in mm




Fig. 3 Mounting thread for direct fastening


➤ Preferably mount the mounting rail flat on the four mounting holes M5, blue color.

Information on other mounting options can be found in the operating instructions.

Mounting, Structure of Components, Mounting Rail

➤ Mount the sensor (light source and receiver on the mounting rail), see Fig. 2.

➤ Connect the sensor with a power supply unit to a laptop / PC.



i Position the light source and receiver so that the connections and displays are not concealed. Do not bend the cables more tightly than the bending radii.

Freestanding Mounting on Your Own Device

Only attach the light source and receiver using the existing holes on a flat surface. Any type of clamping is not permitted.

> Inaccurate or incorrect measurements

If light source and receiver must be installed without the supplied mounting rail, you must make sure that the components are exactly aligned with each other.

i Light source and receiver must be located on the same plane and must not be tilted in relation to each other!

➤ After installation of light source and receiver, check the centered alignment of the light band on the receiver at the correct distance. If necessary, loosen the light source for exact positioning.




Fig. 4 Direct fastening of sensor




Fig. 5 Errors to be avoided with free mounting




Fig. 6 Pin assignment for the 12-pin M12 socket

Supply, Synchronization, RS422

Signal	Pin	Wire color PC/SC2700-x, Explanation	Notes
V ₊	9	Red	Supply voltage 11 ... 30 VDC, typ. 24 VDC, I _{max} 230 mA at 24 VDC
GND	2	Blue	Reference ground Reference ground for Power, Sync, RS422
Sync +	1	Brown	Synchronization Symmetrical, RS422 level, terminating resistor (120 ohm), direction can be switched using soft- ware, not electrically separated
Sync -	3	White	
Tx +	5	Pink	RS422 Interface RS422, symmetrical, Rx internally terminated with 100 ohm, max. 4 MBaud, full duplex, not electrically separated
Tx -	8	Gray	
Rx +	4	Green	
Rx -	6	Yellow	

Fig. 6 Pin assignment for the 12-pin M12 socket

The PC/SC2700-x has a 12-pin M12 connector and open ends on the other side.


Analog Output, Switching Outputs and Inputs

Signal	Pin	Wire color SCA2700-x, Explanation	Notes
Analog output ¹	1	White	not electrically separated, 16 Bit D/A Current 4 ... 20 mA Voltage 0 ... 5 VDC Voltage 0 ... 10 VDC
AGND ¹	2	Black	Ground analog output
Switching output 1	11	White	Switching behavior NPN, PNP, push-pull or push-pull negat- ed Function either limit value or number of edges
Switching output 2	9	Green	
Switching output 3	16	Yellow	
Multifunction input 1	15	Pink	24 V logic (HTL): Low ≤ 3 V; High ≥ 8 V (max 30 V) 5 V logic (TTL): Low ≤ 0.8 V; High ≥ 2 V
Multifunction input 2	12	Red/blue	internal pull-up resistor, an open input is detected as High. Connect the input to GND to trigger the function.
Multifunction input 3	17	Gray/pink	Function either triggering or encoder
GND	10	Brown	Reference ground for the switching inputs and outputs
GND	8	Gray	

Fig. 7 Pin assignment 17-pin M12 connector

The SCA2700-x has a 17-pin M12 socket and open ends on the other side.

1) Internal coaxial cable for analog output in SCA2700-x.



Proper Environment

- Protection class: IP67; unused connectors sealed with protective cap
- Temperature range:
 - Operation: 0 °C ... +50 °C
 - Storage: -20 ... +70 °C
- Humidity: 5 ... 95 % RH (non-condensing)
- Ambient pressure: Atmospheric pressure

i The protection class is limited to water (no penetrating liquids, detergents or similarly aggressive media). Use a protective housing if there is constant exposure to water.

Optical windows are excluded from the protection class. Contamination of the windows causes impairment or failure of the function.

Warnings

Connect the power supply according to the safety regulations for electrical equipment. The supply voltage must not exceed the specified limits.
> Risk of injury, damage to or destruction of the system.

Protect the cables against damage. Never bend the cable more tightly than the bending radius.
> Failure of the measuring device, damage to and destruction of the cable.

Avoid shocks and impacts to the light source and receiver.
> Damage to or destruction of the system

Light Source


The light source for optoCONTROL 2700 uses an LED with a wavelength of 508 nm.
The LED light source is not covered by the laser standard.

MICRO-EPSILON Eltrotec GmbH
Manfred-Wörner-Straße 101
73037 Göppingen / Germany
eltrotec@micro-epsilon.de
www.micro-epsilon.com
Your local contact: www.micro-epsilon.com/contact/worldwide/

Ethernet

Signal	Pin	Notes
Tx +	1	Ethernet
Rx +	2	
Tx -	3	
Rx -	4	

Connections Receiver



LEDs on Receiver

LED	Color	Meaning
Status	Yellow	If synchronization error
	Flashing red	Ethernet, error
	Yellow	Loading factory settings
Speed	Green	Zeroing/mastering
	Yellow	If baud rate 100 Mb
Link	Off	If link inactive
	Flashing	If network activity
Power	Green	Supply voltage On



Fig. 11 LEDs on receiver

Connection Options




Fig. 12 Connection examples on the optoCONTROL 2700-40

Using the 12-pin socket Power/RS422, various peripherals¹ can be connected with the connecting cables shown¹.

1) The various peripherals and connecting cables are available as optional accessories, see also operating instructions, Chapter "Optional Accessories".



SCIGATE AUTOMATION (S) PTE LTD

No.1 Bukit Batok Street 22 #01-01 Singapore 659592
 Tel: (65) 6561 0488 Fax: (65) 6562 0588
 Email: sales@scigate.com.sg Web: www.scigate.com.sg

Business Hours: Monday - Friday 8.30am - 6.15pm

Quick Guide

The sensor is shipped with the factory-set IP address 169.254.168.150.

You can query the IP addresses of the sensors that are connected to a PC or network by using the sensorTOOL.exe program.


➤ Launch the sensorTOOL program and click on the button.

➤ Select the correct sensor from the list.

➤ Click the Open Website button to connect the sensor to your default browser.

The sensorTOOL program is available online at <https://www.micro-epsilon.com/fileadmin/download/software/sensorTool.exe>.

The start screen of the sensor software should now be displayed in the web browser:



In the top navigation bar, other functions (settings, measurement chart etc.) are available. All settings on the web page are implemented in the sensor immediately after clicking the Save settings button. Parallel operation with web browser and ASCII commands is possible; the last setting applies.

You can download a PDF of the detailed operating instructions from our website: <https://www.micro-epsilon.de/download/manuals/man--optoCONTROL-2700--en.pdf>



Selecting Measuring Program

➤ Go to the Home > Measurement configuration menu. Here you will find predefined presets for common measurement tasks.

➤ Go to the menu Settings > Data acquisition > Measurement program. Here you will find setups for individual measurement tasks.

➤ Select the appropriate preset or setup.

Performing Light Referencing

This referencing must be performed at least once after installation. But can also be repeated very frequently if great accuracy is required.

➤ The sensor requires a warm-up time of at least 30 minutes before a light correction can be performed.

➤ Go to the menu Settings > Corrections/Referencing > Light correction.

➤ During light correction, no measuring object must be in the measuring range.

➤ Click the Execute button to start light referencing.

Positioning the Target

➤ Position the measured object at the measuring distance to the receiver, as much as possible in the center of the measuring range.

➤ The Setup mode in the Measurement chart menu helps you position a measurement object. Setup mode should be switched off in measurement mode to reduce the amount of data to be transmitted.

Checking the Video Signal

➤ Click the Video button in the footer and check the signal.

You can suppress edges at the start and end of the measuring range that are not to be evaluated. Change the Evaluation range in the menu Settings > Data acquisition.

Checking the Measurement

➤ Go to the Measurement chart menu and check the measured value-time diagram.

Here you can select additional data for display, e.g., individual edges or center axes.

Saving the Settings

➤ Save the current settings in the receiver using a setup.

➤ Go to menu Settings > System settings > Load & Save. Alternatively, press the Save settings button in the horizontal menu control.

Without saving, the settings will be lost when the receiver is turned off.