

Preface

Thank you for purchasing Digital's Pro-face GLC100 Series of Graphic Logic Controllers (hereafter referred to as the "GLC unit").

Please read this manual carefully as it explains, step by step, how to use the GLC correctly and safely.

Also, in this manual's examples, the Mitsubishi MELSEC-AnA Series PLC is used whenever possible.

-<Note> -

- 1) It is forbidden to copy the contents of this manual, in whole or in part, except for the user's personal use, without the express permission of the Digital Electronics Corporation of Japan.
- 2) The information provided in this manual is subject to change without notice.
- 3) This manual has been written with care and attention to detail; however, should you find any errors or omissions, please contact Digital Electronics and inform them of your findings.
- 4) Please be aware that Digital Electronics Corporation shall not be held liable by the user for any damages, losses, or third party claims arising from the uses of this product.
- 5) This product conforms to the CE Marking and cUL standards. However, be aware that, when using this product together with expansion units that do not conform to those standards, this product may not perform consistent with those standards.

All Company/Manufacturer names used in this manual are the registered trademarks of those companies.

© Copyright 2000, Digital Electronics Corporation

Table of Contents

Preface1		
Table of Contents	2	
Safety Precautions	6	
UL/c-UL(CSA) Approval		
CE Marking		
What is IP65f?		
Package Contents		
Separately Sold Manual		
Documentation Conventions		

Chapter 1 Introduction

1.1	Operating the GLC	.1-1
1.2	1.2 System Design	
	1. System Configuration	1-3
	2. System Design	1-4
1.3	Optional Equipment	1-6

Chapter 2 Specifications

2.1	1 General Specifications	
	1. Electrical Specifications	2-1
	2. Environmental Specifications	2-2
	3. Structural Specifications	2-2
2.2	Features and Performance	2-3
	1. Display Features	2-3
	2. Screen Memory	2-3
	3. Touch Panel / Clock Accuracy	2-3
	4. External Interfaces	2-4
	5. Control Memory	2-4
2.3	Interface Specifications	2-5
	1. Serial Interface	2-5

2.4	2.4 Names and Functions of GLC Parts	
2.5	Graphic Logic Controller Dimensions	2-8
	1. GLC100 Series - External Dimensions	
	2. Installation Fasteners	
	3. GLC Panel Cut Out Dimensions	

Chapter 3 Installation and Wiring

3.1	Installation	
	1. Creating a Panel Cut Out	3-1
	2. Installation Direction	3-3
	3. Securing the Installation Fasteners	3-3
	4. Inserting and Tightening the Fasteners	3-3
3.2	3.2 Wiring Cautions	
	1. Connecting the GLC's Power Code	3-5
	2. Grounding the GLC	3-7
	3. I/O Unit Attachment Precautions	3-8
	4. Input and Output Signal Line Wiring Precautions	3-8
3.3	Installation Precautions	3-9
3.4	GLC Tool Connector	3-12

Chapter 4 OFFLINE Mode

4.1	4.1 Entering OFFLINE Mode	
	1. When Turning the GLC's Power ON	1
	2. From Force Reset	2
4.2	OFFLINE Mode Main Menu	4-3
4.3	INITIALIZE—Standard Operation	4-4
4.4	GLC SELF-DIAGNOSIS	4-6
4.5	Transferring Screen Data/Logic Program	4-8

Chapter 5 Initializing the GLC

5.1	Initialization Screen	5-1
5.2	Initialization Items	5-2
5.3	SYSTEM ENVIRONMENT SETUP	5-3

	1. SYSTEM SETUP	
	2. SYSTEM AREA SETUP	
	3. GLOBAL WINDOW SETUP	
	4. CHARACTER STRING DATA SETUP	
5.4	SET UP I/O	
	1. SET UP SIO	
	2. SET UP TOUCH PANEL	5-10
	3. COMMUNICATION SETUP	5-13
5.5	PLC SETUP	5-14
	1. SET UP OPERATION SURROUNDINGS	5-14
	2. Controller Setup	5-15
5.6	INITIALIZE INTERNAL MEMORY	5-17
5.7	SET UP TIME	5-17
5.8	SET UP SCREEN	
5.9	SET UP FONT	5-19

Chapter 6 GLC RUN Mode and Errors

6.1	GLC RUN Mode		
	1. After Powering Up the GLC		
	2. Via OFFLINE Mode		
6.2	Troubleshooting		
	1. Possible Types of Trouble		
	2. When Screen Does Not Appear		
	3. When No Communication with PLC is Performed		
	4. When Touch Panel Does Not Work	6-10	
	5. When Logic Program Does Not Operate	6-11	
6.3	SELF-DIAGNOSIS		
	1. GLC SELF-DIAGNOSIS Item List	6-12	
	2. SELF-DIAGNOSIS - Details		
6.4	Error Messages		
	1. Error Message List	6-15	
	2. Error Message Details	6-16	

Chapter 7 Maintenance

7.1	7.1 Regular Cleaning	
	1. Cleaning the Display	7-1
	2. Moisture Resistant Gasket Replacement	7-2
7.2	Changing the Backlight	.7-4

Safety Precautions

This manual includes the information that must be followed in order to operate the GLC correctly and safely. Be sure to read this manual as well as any related manuals to thoroughly understand the correct operation and functions of your GLC.

Usage of Icons

Throughout this manual, to ensure that you to use the GLC correctly, the following icons are provided to indicate items requiring special attention. The items described with these icons contain essential safety information. Be sure to follow this information. The following are examples of the icons and their meanings:



Indicates situations where severe bodily injury, death or major machine damage will occur.

Indicates situations where severe bodily injury, death or major machine damage can occur.

Indicates situations where slight bodily injury or machine damage can occur.

DANGERS
 Design Precautions Set up all safety circuit(s) outside the GLC to ensure that the entire system operates appropri- ately to ensure safety, even when an external power or GLC unit malfunction occurs. Other- wise, an accident can occur due to incorrect signal output or incorrect operation. (1) Set up all emergency stop and protection cir- cuits, interlock circuits for opposite move- ments such as forward and reverse revolu- tions, and interlock circuits for machine dam- age protection such as upper, lower and run (drive) limits in positioning, outside of the GLC.



Wiring Precautions

- Prior to installing the unit or when connecting any cables and lines to the GLC, be sure to confirm that the power cable is not connected, to avoid the possibility of an electric shock.
- After wiring is completed, be sure to replace the terminal block's plastic cover, otherwise, an electric shock can occur.
- High voltage runs through the GLC. Except for replacing the backlight, NEVER disassemble the GLC, otherwise, an electric shock can occur.
- Do not use the GLC in an operating environment that is inconsistent with that designated by this manual's specifications since it can cause an electric shock, fire, malfunction, or damage to the GLC.
- Do not use the GLC in an environment where flammable gasses are present, otherwise, operating the GLC may cause an explosion.

Start-up and Maintenance Precautions

- Do not touch the power terminals while the GLC's power is ON, otherwise, an electric shock or incorrect operation can occur.
- Prior to cleaning the unit or retightening the terminal screws, be sure to confirm that the GLC's power cable is not connected. Otherwise, an electric shock can occur.
- Prior to replacing the backlight, be sure to disconnected the unit's power cord and wear gloves to prevent burns or an electric shock.
- The GLC uses a lithium battery for its internal clock and for backing up control memory data. If the battery is incorrectly replaced (i.e. if the + and - sides are reversed), the battery can explode. Therefore, before replacing the battery, Digital recommends you contact your local GLC distributor.
- Do not modify the GLC, otherwise, an electric shock or fire can occur.

Circuit Design Precautions

• Be sure to install all input and output signal lines in a separate conduit, away from all power cables. Otherwise, incorrect GLC operation may occur due to power cable noise.

Reference 3.2.4 Input and Output Signal Line Wiring Precautions

Installation Precautions

- Be sure to use the attachment screws (accessory) to attach the I/O unit to the GLC. If the I/O unit is not attached correctly, incorrect GLC operation may be caused, the I/O unit may malfunction or fall off the back of the GLC unit.
- Be sure to securely connect all cables to their connectors, and confirm that all the set screws and pinch-clips are secured. Otherwise, incorrect input or output may be caused due to insufficient contact. Wiring Precautions
- Ground the GLC FG line separately from other units' FG lines. Otherwise, an electric shock or incorrect operation may occur. Be sure to use a grounding resistance of 100W or less and a 2mm² or thicker wire, or your country's applicable standard.
- In order to perform wiring of the GLC correctly, be sure to confirm that the rated voltage and terminal layout are within the designated specification range. If the supplied voltage differs from the rated one, or incorrect wiring or grounding is performed, it may cause a fire or unit malfunction.
- Use the designated torque to tighten the terminal block screws. If these screws are not tightened firmly, it may cause a short-circuit, fire, or incorrect operation.
- Be careful that metal filings and wiring debris do not fall inside the GLC. Otherwise, a fire, unit malfunction, or incorrect operation may occur.

Start-up and Maintenance Precautions

- Prior to performing a program change, forced program change, RUN, STOP, or PAUSE operations during regular GLC operation, be sure to read this product's instruction manual(s) and on-line help information and understand them thoroughly to ensure the safe operation of your GLC. Incorrect operation may cause an accident or machine damage.
- Prior to attaching or removing the I/O unit, be sure to confirm that the GLC's power cable is not connected. If the attachment or removal of the I/O unit is performed while the power cable is connected, the I/O unit may malfunction or incorrect operation may occur.
 GLC Disposal Precautions
- When disposing of this unit, process it as you would industrial waste.

To Prevent GLC Damage:

- Never strike the touch panel with a hard or heavy object, or push on the touch panel with too much force, since it may damage the unit.
- If the GLC is used in an environment with temperatures and humidity in excess of the allowed range, the GLC may malfunction and/or its useful life may be shortened.
- Do not allow water, liquids, metal particles, or charged particles to enter inside the GLC's chassis, since they can cause either a GLC malfunction or an electrical shock.
- Do not use this unit in areas where the temperatures can change drastically, causing condensation to form inside the unit. This can cause the unit to malfunction.
- Avoid restricting the GLC's naturally occurring ventilation, or storing or using the GLC in an environment that is too hot.
- Avoid using or storing the GLC in direct sunlight, or in excessively dusty or dirty environments.
- Because the GLC is a precision instrument, do not store or use the GLC where a sudden shock or excessive vibration can occur.
- Do not store or use the GLC where chemicals and acids evaporate, or where chemicals and acids are present in the air.
- Do not use paint thinner or organic solvents to clean the GLC.
- Due to the danger of unforeseen accidents, be sure to back up the GLC's screen data and logic programs regularly.
- After turning this unit OFF, be sure to wait a few seconds before turning it ON again. If the unit is started too soon, it may not start up correctly.

About the GLC's Display Panel:

- The Display Panel contents and the Contrast Adjustment affect the intensity of *Contouring*. (i.e, when some parts of the screen are brighter than others, creating a wavelike pattern)
- There are minute grid-points(dark or light) on the Display Panel's surface. This is part of the GLC's design and not a defect.
- Shadows may appear at the top of the LCD. This is normal for an LCD display.
- Sometimes the display area may look as if the display colors have changed. This is a common attribute of LCD's and is not a defect.
- Displaying a single image for long periods can cause an afterimage to remain when the display is changed to another screen.

To prevent this effect:

• Set up the GLC's "Stand-by Mode", which turns the screen OFF automatically when there is no input for a specified period of time.

Reference 5.3.1 SYSTEM SETUP

• Do not display any single screen for a long period of time. Try to always change the screen display periodically.

UL/c-UL(CSA) Approval

The GLC100-LG41-24V, and the GLC100-SC41-24V units are UL/c-UL listed products. (UL file No.E182139).

This unit conforms to the following standards:

UL508

Industrial Control Equipment

♦ UL1604

For use with Electrical Equipment in Class I and II, Division 2 and Class III Hazardous (Classified) Locations in industrial control applications.

CAN/CSA-C22.2, Nos. 142 and 213-M1987

Standard for Safety of Information Technology Equipment, including Electrical Business Equipment.

GLC100-LG41-24V (UL Registration Model: 0980017-01) GLC100-SC41-24V (UL Registration Model: 0980017-02)

<Cautions>

- This unit must be installed so that its front face faces the user.
- If natural air cooling is used, the GLC must be installed into an upright panel. In addition, open space of 100 mm or more is required in all directions behind the unit's rear face. Unless this requirement is satisfied, the temperature inside the GLC's components may rise beyond the limit specified by UL standards.

UL1604 Compliance Conditions and Operating Precautions

- 1. Power, input and output (I/O) wiring must be in accordance with Class I, Division 2 wiring methods, Article 501-4 (b) of the National Electrical Code, NFPA 70 or as specified in Section 18-152 of the Canadian Electrical Code for installations within Canada and in accordance with the authority having jurisdiction.
- 2. Suitable for use in Class I, Division 2, Groups A, B, C and D hazardous location, or nonhazardous locations only.
- 3. WARNING: Explosion hazard-substitution of components may impair suitability for Class I, Division 2.
- 4. WARNING: Explosion hazard-do not disconnect equipment unless power has been switched off or the area is known to be nonhazardous.
- 5. WARNING: Explosion hazard-when in hazardous locations, turn off power before replacing or wiring modules.

CE Marking

The GLC100-LG41-24V and GLC100-SC41-24V graphic logic controllers are CE-marked products complying with EMC directives EN55022 class A and EN50082-2.

What is IP65f?

This unit's protection rating of IP65f is actually a composite code, consisting of the internationally recognized British "Ingress Protection" standard (BS EN 60529:1992) - "IP65", and the standard developed by the Japanese Electronics Manufacturer's Association (JEM) - "f". This code is used in this manual to identify a given product's degree of structural resistance to a variety of environmental elements and thus, prevent problems or accidents related to the inappropriate use of a product.

The individual meaning of each character of this code is explained below. This code indicates the degree of ingress protection provided from the front face of the GLC, and assumes that the GLC is securely mounted into a metal panel.

IP 5 f 6 (1) (2) (3)(4)

(1) Designates the type of protection provided.

(2) Indicates the degree of protection provided to the human body by the unit, and the degree of protection provided by the unit's front face from particles/dust intrusion into the interior of the unit.

Here, "6" indicates that the unit is completely protected from dust intrusion.

(3) Indicates the degree of protection provided by the unit's front face from water intrusion into the interior of the unit.

Here, "5" indicates that the unit is protected from water intrusion from a direct water jet.

(4) Indicates the degree of protection provided by the unit's front face from oil particle intrusion into the interior of the unit.

Here, "f" indicates that the unit is completely protected from oil intrusion via either oil particles or oil splashes from any direction (to the front panel).



Note: For information about the GLC's protective structure, refer to page 2-3.

Package Contents

The GLC's packing box contains the items listed below. Please check to



■ Installation Guide (1)



Installation fasteners (4/set)



This unit has been carefully packed, with special attention to quality before shipment. However, should you find anything damaged or missing, please contact your local GLC distributor immediately for prompt service.

Separately Sold Manual

■ GLC100 Series **User Manual** (sold separately)



(this manual)

Documentation Conventions

The list below describes the symbols used in this manual.

Symbol	Meaning
Important	Failure to observe this instruction may cause abnormal operation of equipment or data loss.
Pro-Control	Name of software that creates, transfers, and monitors the GLC's
Editor	logic program.
GLC	Represents the GLC100-LG41-24V or GLC100-SC41-24V.
GP Screen Editor	Indicates the GP-PRO/PBIII for Windows Ver. 3.0 (or later) screen editor software.
Logic Program	Represents the ladder program that is created using the Pro-Control Editor software.
*1	Indicates useful or important supplemental information.
Note:	Used to provide useful or important supplemental information.
Reference	Used to refer to useful or important supplemental information.
PLC	Abbreviation for Programmable Logic Controller.



- 1. Operating the GLC
- 2. System Design
- 3. Optional Equipment

Chapter

1

Introduction

1.1 Operating the GLC

The following example procedures are required for starting to use the GLC.

1	Preparation	Before using the GLC, check that all required hardware is present and read all specification, wiring, and installation information. Reference Chapter 2, Specifications, and Chapter 3, Installation and Wiring
2	Design	Design the GLC screen images, layout of tags and logic program.
3	Screen Editor Software Installation	Install the screen editor software in your personal computer. Reference GP-PRO/PBIII for Windows Operation Manual (included in the screen editor software package)
4	Logic Program Development Software Installation	Install the logic program development soft- ware in the personal computer where the screen editor software has already been installed. Reference Pro-Control Editor Opera- tion Manual (included in the Pro-Control Editor package)
5	Screen Creation/ Screen Animation Settings/ Screen Data Transfer	Use the screen editor software to create screens and transfer their data to the GLC. Reference GP-PRO/PBIII for Win- dows Operation Manual (included in the screen editor software package)

6 Logic Program Creation/Transfer/ Monitor	Use the logic program development software to create the logic program, set up the operation modes, and to transfer the program to the GLC unit. The transferred logic program can be checked via the logic program development software's monitor feature.
	Reference Pro-Control Editor
	<i>Operation Manual (included in the Pro- Control Editor software package)</i>
7 Initial Settings	Perform GLC's initial settings, according to the type of usage.
	Reference Chapter 5, Initializing the GP, and the GP-PRO/PB III for Windows PLC Connection Manual (included in the screen editor software package)
8 Operation	Connect the GLC and expansion unit, as well as peripheral devices required, and start operation.
	Reference GP-PRO/PBIII for Windows PLC Connection Manual (included in the screen editor software package) and each expansion unit's User's Manual

1.2 System Design

1. System Configuration

The GLC can be used in either of the following systems.

Stand-alone System

The expansion unit can be attached to the GLC to perform I/O control.



PLC Connection System

Connecting the GLC to a PLC allows you to send data between the GLC and a PLC. At the same time, the Expansion unit can also be attached to the GLC to perform I/O control.



2. System Design

The following peripheral devices can be used being connected with the GLC100 unit:



*1 Personal computer running Windows 95/98/NT4.0

Items shown with the codes (3) to (4) should be connected to the following devices.

GLC Interface

PLC/Personal Computer Interface

- (1) Tool connector
- (3) RS-232C port
- (2) Serial interface
- (4) RS-422 port



Optional Products

Sold separately.

Optional Maintenance Products

Attached to the GLC or included in the package box as standard items. Also, sold separately as the optional maintenance items.

1.3 Optional Equipment

The following are the GLC's optional items, which are sold separately.

	Product Name	Description
I/O Unit	DIO unit	• Up to 2 units can be attached to
	•I/O unit for mounting	the GLC unit's rear face.
	GLC 100 SETIES	• Via the user program, GLC can
	GLC100-S141: SINK-Output Type	(Input: 16 points Output: 16
	GLC100-R141: Source-Output Type	points)
Logic Program	Pro-Control Editor	Program creation
Development	(GLCCNT-ED01E-V15)	System settings
Software	•Logic program development software	Program download/upload
		 Program debugging, and
		ladder/device monitor feature to
Saraan		monitor operation status
Creation	GP-PRO/PBIII IOF WINDOWS	GP-PRO/PBIII IOI WIIIuows Ver 2.1 or later
Software	(GPW-PBUTE-V21 OF later [CD])	Software to be used to create
Continuito		the GLC's screen data using a
		personal computer.
Serial	RS-232C cable	Interface cable between the
Interface	(GP-410-IS00-0)	host and GLC.
	RS-422 cable	
	(GP230-IS11-0)	
	RS-422 connector terminal block	Conversion adapter to convert corial data to DS_422 format
		Serial uala lo RS-422 Iomal.
Option	Screen protection sheet	Disposable protective and
	(GP370-DF10-0)	dirt-resistant sheet for the
	(GP370-COVER-20P)	GLC's screen. The GLC's touch
		panel can be used with this
		cover sheet attached.
Optional Maintenance	Backlight bulb (GP-370-BL00-0)	Replacement backlight bulbs
Items	Installation fastener for GP70 series	Fastener to attach the GLC to
	(GP-070-AT00-MS)	a panel.
	Moisture resistant gasket	Provides a moisture resistant
	(GP370-WP10-MS)	Seal when installing the GLC.
		the GLC's original equipment
		package.
Tool	Memory Loader II	Copies data (system and
Connector	(GP-070-LD01-0)	screen data) from the GLC to
	Rev. D or later	GLC.
	Transfer Cable Set	Transfer cable
	(GPW-CB02)	Connects the GLC to a
		personal computer. Transfers
		program(s)

- 1. General Specifications
- 4. Names and Functions of GLC Parts

Chapter

2

2. Features and Performance 5. Graphic Logic Controller Dimensions

3. Interface Specifications

Specifications

2.1 General Specifications

1. Electrical Specifications

	GLC100-LG41-24V	GLC100-SC41-24V
Rated Power Supply DC20.4V to DC27.6V		o DC27.6V
Power Consumption	20W or less	
Voltage Endurance	AC1000V—10mA 1minute (between the live wire and grounding terminals)	
Isolation Resistance	DC500V—above 20M Ω (between the live wire and grounding terminals)	

2. Environmental Specifications

	GLC100-LG41-24V	GLC100-SC41-24V	
Ambient Operating Temperature	0 Cº to 50Cº		
Ambient Storage Temperature	-20 Cº to 60 Cº		
Ambient Humidity	20%RH to 85%RH	(non-condensing)	
Vibration Resistancee	10 to 25 Hz (X, Y, Z directions - 30 minutes each, 19.6m/s ²)		
Noise Immunity (via noise simulator)	Noise voltage: 1000 Vp-p Pulse length: 1 microsecond Arise time (rise/fall): 1 nanosecond		
Operating Atmosphere	Must be free of corrosive gasses		
Grounding	100 Ω or less grounding resistance or your country's applicable standard		
Protective Structure *1	Equivalent to IP65f and NEMA #250 TYPE4X/12 (No protection against freezing)		

*1 The front face of the GLC unit, installed in a solid panel, has been tested using conditions equivalent to the standards shown in the specification. Even though the GLC unit's level of resistance is equivalent to these standards, oils that should have no effect on the GLC can possibly harm the unit. This can occur in areas where either vaporized oils are present, or where low viscosity cutting oils are allowed to adhere to the unit for long periods of time. If the GLC's front face protection sheet becomes peeled off, these conditions can lead to the ingress of oil into the GLC and separate protection measures are suggested. Also, if non-approved oils are present, it may cause deformation or corrosion of the front panel's plastic cover. Therefore, prior to installing the GLC be sure to confirm the type of conditions that will be present in the GLC's operating environment.

If the installation gasket is used for a long period of time, or if the unit and its gasket are removed from the panel, the original level of the protection cannot be guaranteed. To maintain the original protection level, you need to replace the installation gasket regularly.

3. Structural Specifications

	GLC100-LG41-24V GLC100-SC41-24V	
External Dimensions (mm)	170.5W x 138.0H x 57.0D mm (GLC unit only,	
(Tolerance: IT15)	including protrusions on the rear panel)	
Weight	Under 900g (GLC unit only)	
Cooling Method Natural air circulation		circulation

2.2 Features and Performance

1. Display Features

	GLC100-LG41-24V	GLC100-SC41-24V	
Display Medium	Monochrome LCD	STN type color LCD	
Display Colors	Monochrome (black and white)	8 colors (white, red, blue, green, yellow, magenta, cyan, black) Intermediate colors are displayed via tiling.	
	CC	FL	
Backlight	(Service life: 20,000 hrs. at continuous operation) (User replaceable)		
Resolution	320X24	0 pixels	
Display Area	115mm(W)X86mm(H)		
Attributes	Blinking/Reverse video		
Brightness Control	2 levels (via touch panel)		
Contrast Control	8 levels (via	touch panel)	
Character Sets	Japanese: ANK 158, Kanji: 6349 (Including 453 kinds of non-Kanji characters, JIS Standards 1 & 2)		
	8X8 dots: 40 charactersX30 rows		
No. of Characters Displayed	8X16 dots: 40 charactersX15 rows		
No. of Characters Displayed	Nanji characters: ToX To dots:		
	Larger than 32X32 dots: JIS Standard 1		
Character Sizes	Fonts enlarge in multiples of 1, 2, 4, and 8 (high quality fonts are used for the characters larger than 32X32 dots)		

2. Screen Memory

	GLC100-LG41-24V	GLC100-SC41-24V	
	FLASH EPROM 1MB (for 320 standard screens, each		
nternal Memory	an average of 3.2 KB)		
	SRAM 128KB (with a backup function)		

3. Touch Panel / Clock Accuracy

	GLC100-LG41-24V GLC100-SC41-24	
Touch Panel	16 × 12 keys/screen (1 or 2 point touch)	
Clock Accuracy	+/-65 seconds/month (at room temperature)	

4. External Interfaces

	GLC100-LG41-24V	GLC100-SC41-24V	
Serial Interface	Asynchronous Transmission Method: RS232C/RS422 (Supports various protocols) Data Length: 7 or 8 bits Stop Bit: 1 or 2 bits Parity: None, Odd or Even Data Transmission Speed: 2400 to 38400bps		
Tool Connector	cool Connector RS-232C synchronous TTL level nonprocedural command I/F cool Connector Screen and Program Development> Used as the interface to download data from the GP screen economic software. <during operation=""> Used as a bar code reader's interface</during>		

5. Control Memory

	GLC100-LG41-24V	GLC100-SC41-24V
Backup Memory ^{*1}	SRAM 128KB (Backup require Backup time period: Approxima battery. Approximately 6 days with the (Battery lifetime: 10 years or m 40°C or lower. 4.1 years or more at an ambier 1.5 years or more at an ambier	s lithium batteries) ately 60 days with a fully charged battery service life almost finished. ore at an ambient temperature of nt temperature of 50°C or lower. nt temperature of 60°C or lower.)

*1 The battery life of the GLC100's lithium battery, when the battery is 40°C or less is over 10 years. At 50°C or less it is over 4.1 years, and at 60°C or less it is more than 1.5 years. The backup time period lasts approximately 60 days in its initial condition (fully charged), and approximately 6 days when the battery life is almost finished.

2.3 Interface Specifications

1. Serial Interface

Pin Connection	Pin #	Signal Name	Condition
	1	FG	Frame ground
	2	SD	Transmit Data (RS-232C)
SIO	3	RD	Receive Data (RS-232C)
	4	RS	Request To Send (RS-232C)
$(\overline{\mathbb{A}})$	5	CS	Clear To Send (RS-232C)
	6	NC	Not Connected
	7	SG	Signal Ground
l o o o	8	CD	Carrier Detect (RS-232C)
0 0 14	9	TRMX	Termination (RS-422)
	10	RDA	Receive Data A(RS-422)
	11	SDA	Transmit Data A (RS-422)
o.o	12	ALRM OUT	External alarm output
	13	ALRM GND	External alarm ground
l 0 õ	14	VCC	5V±0.5 output 0.25A
	15	SDB	Transmit Data B (RS-422)
	16	RDB	Receive Data B (RS-422)
	17	NC	Not Connected
13	18	CSB	Clear To Send B (RS-422)
· · · · · · · · · · · · · · · · · · ·	19	ERB	Enable To Receive B (RS-422)
	20	ER	Enable To Receive (RS-232C)
	21	CSA	Clear To Send A (RS-422)
	22	ERA	Enable To Receive A (RS-422)
	23	BUZZ GND	External buzzer ground
	24	NC	Not Connected
	25	BUZZ OUT	External buzzer output

Recommended Connector:Dsub25-pin plug XM2A-2501<made by OMRON Corp.>Recommended Cover:Dsub25-pin cover XM2S-2511<made by OMRON Corp.>Jack Screws XM2Z-0071<made by OMRON Corp.>



Use rough metric type M2.6x0.45p threads used to secure the cable's set screws. Recommended Cable: CO-MA-VV-SB5Px 28AWG <made by HITACHI Cable Ltd.> To determine your PLC's connection:

Reference GP-PRO/PBIII for Windows PLC Connection Manual (included in the screen editor software package)



- Be sure to connect the SG terminal to the correctly corresponding SG terminal of the host (via the cable). Use the FG terminal only when necessary.
- This unit's RS-485 (RS-422) port does not support the isolation function. Especially when the host is not isolated, be sure to connect the SG terminal. Otherwise, RS-485 (RS-422)'s circuit may malfunction.

When creating your own cable, follow the instructions listed below: **For RS-422** (The following pairs of pin #'s must be connected to each other) #18 (CSB) < -> #19 (FRB)

$$\#10 (CSB) < \#19 (ERB)$$

 $\#21 (CSA) < \#22 (ERA)$

- When connecting the RS-422 cable and the #9 (TRMX) and #10 (RDA) points, a termination resistance of 100Ω is added between RDA and RDB.
- When making a cable for the Memory Link format, be sure to select a 4-line System.

For RS-232C

• Do not use the following pins: 9 (TRMX), 10 (RDA), 11 (SDA), 15 (SDB), 16 (RDB), 18 (CSB), 19 (ERB), 21 (CSA), 22 (ERA).

<External Buzzer Output>

• Use #23 (BUZZ GND) and #25 (BUZZ OUT) pins when performing external buzzer output.



GLC-100 Unit Internal Structure

<External Alarm Output>

• Use #12 (ALRM OUT) and #13 (ALRM GND) pins to output an alarm for abnormal watchdog timer output.



GLC-100 Unit Internal Structure

2.4 Names and Functions of GLC Parts





A: Display Panel

The GLC monitor screen displays the screen setup and corresponding PLC host data.

GLC100-LG41-24V: Monochrome type LCD

GLC100-SC41-24V: STN type Color LCD

B: Touch Panel (overlaid on top)

Performs any screen change operations and sends data to the PLC.

C: Status LED

Lights according to operation status.

Color	LED status	Operation Mode	Controller's Mode
Green	Lit	OFFLINE	STOP
	Lit	RUN	RUN
	Blinking	RUN	STOP
Orange	Lit	RUN	Initial Processing
Red	Lit	RUN	Major Error

D: Power Input Terminal Block

The input and ground terminals for the power cable.

E: Expansion Interface

Used to connect a variety of I/O units.

F: Serial Interface

Used for the RS-232C and RS-422 (Serial) cables. Is connected to the Host (PLC).

G:Printer Interface

The Printer is connected here.



1. GLC100 Series - External Dimensions

Note: For detailed dimension information, please contact your local GLC distributor. Unit: mm(in.)





GLC100 Series User Manual

2. Installation Fasteners

Unit: mm (in.)







3. GLC Panel Cut Out Dimensions

Unit: mm (in.)

Panel Cut Out



- 1. Installation
 - 2. Wiring Cautions
 - 3. Installation Precautions
 - 4. GLC Tool Connector

Installation and Wiring

3.1 Installation

Chapter

3

Follow the steps given below when installing the GP100 Series unit.

Confirm the Installation Gasket's Seating

It is strongly recommended that you use the gasket.

Place the GLC on a level surface with the display panel facing downward. Check that the GLC's installation gasket is seated securely into the gasket's groove, which runs around the perimeter of the panel's frame.

For details about installing the gasket, refer to







Before installing the GLC into a cabinet or panel, check that the Installation gasket is securely attached to the unit.

1. Creating a Panel Cut Out

Create the correct sized a Panel Cut Out required to install the GLC, using the installation dimensions given.

Reference 2.5.3 GLC Panel Cut Out Dimensions

The moisture resistant gasket, installation brackets and attachment screws are all required when installing the GLC.



Chapter 3 - Installation and Wiring



• Be sure that heat from surrounding equipment does not cause the GLC to exceed its standard operating temperature.

- Use this unit in areas where the ambient operating temperature is from 0 °C to 50 °C and the ambient relative humidity is from 20% to 85%.
- As a general rule, the GLC is supposed to be installed vertically. When the GLC must be tilted for some reason, be sure to tilt it within 30 degrees.



- If the GLC must be tilted more than 30 degrees, be sure to use the unit in areas where the ambient operating temperature becomes 40°C or lower.
- When installing the GLC vertically, orient the unit so that the Power Terminal Block points upwards.
- For easier maintenance and operation, plus better ventilation, ensure the GLC unit (including I/O units) is mounted at least 100 mm (3.94in.) away from adjacent structures and other parts.



- Be sure this unit is located as far away as possible from electromagnetic circuits, non-fuse type breakers, and other equipment that can cause arcing.
- It is important that the panel or cabinet's surface is flat, in good condition, and without any jagged edges for better water-resistance. To prevent the panel or cabinet's surface from bending, reinforcing stays can be attached (welded) to its inner surface.
- Panel thickness should be from 1.6mm to 5.0mm (from 0.06in. to 0.2in.)



2. Installation Direction



3. Securing the Installation Fasteners

There are four (4) insertion slots on the top and bottom of the GLC, where the metal installation fasteners hook on.



4. Inserting and Tightening the Fasteners

Insert each of the fasteners into its slot as shown below. Be sure to pull the fastener back until it is flush with the rear of the attachment hole.



Chapter 3 - Installation and Wiring

Use a screw driver to tighten the attachment screws and secure the GLC unit in place.





• A torque of only 0.5 to 0.6 N•m is required to tighten an attachment screw. Be careful not to use too much force, since it may damage the GLC unit.
3.2 Wiring Cautions

1. Connecting the GLC's Power Cord



- To avoid electric shocks, be sure the Power Cord is unplugged from the power outlet when connecting the power terminals to the GLC unit.
- The GLC100 series accepts CD24V power input only. Using a power supply not made for the GLC or, using a power supply with incorrect polarity will result in damage to both the power supply and the GLC.
- After wiring is completed, be sure to reattach the plastic terminal block cover to prevent an electric shock.



• When the FG terminal is connected, be sure the wire is grounded. Not grounding the GLC unit will result in excess noise.



- Wherever possible, use thick wires (max 2mm²) for power terminals, and twist the exposed wire ends when connecting the Ring Terminals.
- Please use the following sized Ring Terminals.

under 6.0mm(0.24in.)

over Ø3.2mm(0.13in.)

• To prevent the Ring Terminals from causing a short when the terminal block attachment screws are loosened, be sure to use sleeve-type Ring Terminals ^{*1}.

*1 FG = Frame Ground terminal - connected to the GLC chassis Recommended ring terminal: V2-MS3 or equivalent (Made by JST Corporation)

Chapter 3 - Installation and Wiring

To connect the GLC's power cord terminals:

- 1) Confirm that the power cord is unplugged from the power supply.
- 2) Remove the power terminal block's cover using a Phillips screwdriver.
- 3) Remove the power terminal block's three attachment screws. After placing the Ring Terminals on the screw holes, replace the screws to secure the Ring Terminals in place.
 - Be sure to attach the Ring Terminals in the correct order.
- 4) Reattach the power terminal block's cover using a Phillips screwdriver.

Appropriate tightening torque range is 0.5 to 0.6 N·m.



2. Grounding the GLC

(a) Exclusive grounding (BEST)

GLC unit other equipment



- (b) Common grounding (OK) GLC unit other equipment
- (c) Common grounding (Not OK) GLC unit other equipment



- Connect the FG terminal found at the back of the unit to an exclusive ground. [diagram (a)].
- Check that the grounding t resistance is less than 100 Ω .
- The grounding wire should have a cross sectional area greater than 2mm^{2*1}. Set the connection point as close to the GLC unit and make the wire as short as possible. When using a long grounding wire, replace the thin wire with a thicker wire placed in a duct.
- If exclusive grounding is not possible, use a common connection point. [diagram (b)]
- If the equipment does not function properly when grounded, disconnect the ground wire from the FG terminal.



Do not place power lines over wires used for grounding the GLC, since it can lead to an accident or machine malfunction.

*1 Also, the grounding wire should meet your country's applicable standard.

3. I/O Unit Attachment Precautions

■ I/O Unit Attachment

Prior to attaching the I/O unit to the GLC, first connect the power cable to the GLC and then confirm that the electricity is not turned ON to the GLC unit and I/O cable.

NEVER attach or remove the I/O unit with the electricity turned ON, otherwise it can cause the unit to malfunction or to be damaged.

Reference For the attachment method of the I/O unit to GLC, refer to each **I/O unit's User's Manual.**

4. Input and Output Signal Line Wiring Precautions

Wiring of the Input and Output Signal Lines

Install the input and output signal lines in a separate conduit from that for the power cables. Also, be sure to keep sufficient distance from any power cables so that the signal lines are not influenced by induced noises and power from the power cables.



When these lines and cables need to be installed in the same conduit, be sure to use grounded steel plate partitions to separate them.





If power circuit cables cannot be installed separately, use shielded cables and ground the shielded end.

3.3 Installation Precautions

When an external power problem occurs or the GLC unit malfunctions, abnormal GLC operation may occur.

In order to prevent these problems from causing a system malfunction, as well as to ensure the system's fail-safe design, be sure to set up all circuits that can cause machine damage or accidents by abnormal operation, such as emergency stop, protection, and interlock circuits, outside the GLC.

The following are system design circuit examples, designed to enhance the system's reliability and provide optimal performance.

Electric Circuit's Fail-safe Design

When designing the circuit structure, be sure to consider that an equipment malfunction may occur when the GLC starts up, due to start-up time differences between the control equipment (specifically DC power equipment) connected to the GLC's output unit, the GLC unit, and the GLC's program. When using a remote I/O unit, create a program that checks the terminal's status via a logic program.

For example, first, connect voltage relay coils to the GLC output unit's power circuit and to the control equipment's power circuit. Then, connect their contacts to the GLC's input unit. Be sure to set up the circuit so that the ladder program of any control equipment connected to the GLC output unit is performed only after checking the voltage relay ON signals via the logic program.

Power Supply Voltage

The power supply should be in the range of DC24V +/-%.

■ Automatic Power Shut-off

When the power voltage's instantaneous failure continues 20ms or more, the GLC's power is turned OFF.

When this occurs, any arithmetic operation in progress is stopped.

For example, if power is turned OFF while 100 words of data are being transferred by the FMOV command, this data transfer is stopped in the middle.

When designing the program, be sure to consider this function.

Emergency Stop Circuit

DO NOT build an emergency stop signal into the GLC and actuate it using a program. Configure the emergency stop signal so that it is outside the GLC, as shown below.



■ Interlock Circuit 1

When controlling the motor's forward/reverse rotation via the GLC or PLC, configure the interlock circuit so that it is outside the GLC, as shown below.





- The GLC and PLC both output their ON/OFF signals to the output equipment at the same time, after the internal program is performed. For example, the electromagnetic switches for motor's forward and reverse rotation are turned ON/OFF at the same time.
- The main power circuit contacts for the motor's forward and reverse revolutions may turn ON at the same time, possibly resulting in a short-circuit of the R and T phases. Therefore, the interlock system described above or electromagnetic switches with a mechanical interlock for these type of circuits are required.

Interlock Circuit 2

When there is a possibility that an accident can occur due to a GLC malfunction, create a fail-safe design so that the interlock circuit uses external hardware.

In a system where the drive motor must first be stopped when the drive limit switch is actuated, never designate that the limit switch sends input to the GLC, using the GLC's software.

Be sure to design the circuit so that only hardware is used to stop the drive motor, as shown below.



3.4 GLC Tool Connector

The GLC's Data Transfer Cable, Memory Loader II, or the Bar Code Reader can be attached to the GLC's Tool Connector socket.

GLC100 Series (side)





- Before unplugging any connector(s) from the back of the GLC, be sure the GLC's power cord is unplugged from the main power supply.
- When the Bar Code Reader uses a separate power supply:
 - Turn the Bar Code Reader ON before turning the GLC ON.
 - Turn the GLC OFF before turning the Bar Code Reader OFF.

Chapter

Entering OFFLINE Mode
 OFFLINE Mode Main Menu
 INITIALIZATION

- 4. SELF-DIAGNOSIS
- 5. Transferring Screen Data

OFFLINE Mode

4.1 Entering OFFLINE Mode

OFFLINE Mode provides access to the Initialize, Self-Diagnosis, and other features built into the GLC. You will need to change the GLC to OFFLINE mode before you can use any of these features.



• OFFLINE mode is unavailable in a completely new GLC until the necessary Screen Data has been transferred from the screen editor software. Be sure the GLC's power cord is plugged in and no images are displayed on the GLC screen. When data is transferred from your PC to the GLC, the necessary System Data will be sent.

To INITIALIZE the setup or run SELF-DIAGNOSIS in the GLC unit, entering the OFFLINE mode becomes necessary. There are two ways to enter OFFLINE mode; first, immediately after plugging in the GLC's power cord, and second, by using the Force Reset feature.

1. When Turning the GLC's Power ON

Touch the upper left-hand corner of the GLC screen within 10 seconds of turning the GLC's power ON.



2. From Force Reset

From the Force Reset screen, touch the OFFLINE button and the Main Menu will appear.

Reference For instructions on how to enter the Forced Reset Screen, refer to **5.4.2** Set Up Touch Panel; FORCE RESET



If a Password has been set in INITIALIZE/ SET UP SYSTEM, before entering the OFFLINE mode, the following screen appears. Enter the password, then touch *Set* to enter OFFLINE mode.

Reference For more information about Passwords, refer to 5.3 SYS-TEM ENVIRONMENT SETUP.

ENTER PASSWORD	SET ESC

4.2 OFFLINE Mode Main Menu

Each menu item shown below has different settings that must be set to match the corresponding PLC in order for the GLC to communicate properly. Entering OFFLINE mode calls up the following screen.

INITIALIZE	
TRANSFER SCREEN [ATA
SELF-DIAGNOSIS	
RUN	

Select the desired menu item by touching the corresponding number on the screen.

Each Main Menu item is used as follows.

INITIALIZE

The setup items listed in this menu are necessary to run the GLC unit.

SCREEN DATA TRANSFER

Select to transfer screen data edited by the screen editing software from personal computer to GLC.

SELF-DIAGNOSIS

Checks to see if there are any problems with the GLC System or Interface (I/F).

RUN

Starts GLC operation.

▼Reference ➤ For more information about INITIALIZE, refer to Chapter 5, Initializing the GLC; for more information about TRANSFER SCREEN DATA, refer to the GP-PRO/PB III for Windows Operation Manual (included in the screen editor software package); for more information about SELF-DIAGNOSIS and RUN, refer to Chapter 6, GLC Run Mode and Errors.

4.3 INITIALIZE—Standard Operation

■ Selecting a Menu

• Touch the menu item to select it.



• Select an item to be set up or touch the input area.



Entering Numbers

• After selecting an input field by touching it, use the numeric touch keys located at the bottom of the screen to enter numeric values. After entering data, touch the [SET] key to register it.



Selecting Setup Conditions

• When selecting a menu, its options appears. Every time the input area is touched, the option is highlighted and selected. Select the desired option (condition) to be set up.



After All Setting Data is Entered

Touch the top-right button, titled "SET".

If you wish to exit the screen without saving the changes, touch the CAN-CEL button.



- Touch the SET key to write the Setup conditions onto the Internal FEPROM, which may take some time, causing a delay in returning to the previous screen. Therefore, do not touch the screen until the previous menu display returns.
- Touch the CANCEL key *not to write* the Setup conditions onto the Internal FEPROM and return to the previous menu.

Return To Previous Screen

Touch the title of the screen you would like to return to.

E.g. To return to the MAIN MENU from the SET UP I/O screen, simply touch the MAIN MENU title.



4.4 GLC SELF-DIAGNOSIS

■ Selecting a Menu

Touch the desired menu item and that sub-display will appear.



■ SET and CANCEL Keys

After selecting the Self Diagnosis item, the SET and CANCEL keys will appear at different times at the top of the screen.

E.g.



SET Key

Registers the entered settings and executes them.

CANCEL Key

When this key is touched, the selected Self-Diagnosis test is cancelled, and you are returned to the SELF-DIAGNOSIS menu.

■ After Check—To Return To SELF-DIAGNOSIS MENU

When OK displays,



Touching once anywhere on the display screen returns you to the SELF-DIAGNOSIS MENU.





After an error message is displayed, in order to return to the self-diagnosis menu screen, touch (1) located on the currently displayed screen's lower left corner and (2) located on the lower right corner simultaneously.

Return To Main Menu

Touch the RETURN Key in the top right corner of the SELF-DIAGNOSIS menu to return to the MAIN MENU.



4.5 Transferring Screen Data/Logic Program

Here, how to transfer or receive screen data, which has been created using the screen editor software, to or from the GLC unit is explained. Prior to transferring or receiving data, connect the GLC to the personal computer via the data transfer cable.

Connect the GLC side face's tool connector and your personal computer's RS-232C connector via a data transfer cable.



*1 Since the data transfer cable has a male connector, another connector is required to convert the cable connector from male to female.

Also, please remember that OFFLINE mode is unavailable in a completely new GLC until the necessary Screen Data has been transferred from the screen editor software.

Therefore, be sure the GLC's power cord is plugged in and no images are displayed on the GLC screen. While screen data is being sent from your PC to the GLC, the necessary System Data will be sent together with it.

To send screen data to a GLC that is currently in OFFLINE mode:

1) From the OFFLINE mode's MAIN MENU, touch the TRANSFER SCREEN DATA item on the screen to enter the TRANSFER SCREEN DATA mode. This will allow the GLC to receive data.



- 2)While data is being transferred, the messages "SETUP Transfer" and "TRANSFERRING/PLEASE WAIT" will display. When data transfer is completed, these messages will be cleared. If desired, use the GLC's Editor Software to stop the transfer.
 - If the Setup^{*1} is performed, the screen will return to the OFFLINE mode's MAIN MENU when data transfer is completed, if the Setup is not performed, the GLC will go ONLINE mode and the screen designated in the "INITIALIZE / INITIALIZE SCREEN" setting will display.

Program Transfer

First, set the GLC's operation mode to "RUN." Transfer the logic program to the GLC via the Pro-Control Editor.

Reference Pro-Control Editor Operation Manual (included in the Pro-Control Editor software package)

^{*1} Set up means to download the GLC's system program and a PLC protocol driver from the screen editor software, in order to run the GLC in a desired environment. This is automatically performed by the screen editor software according the conditions.



Chapter

5

- 1. Initialization Screen
- 2. Initialization Items
- 3. SYSTEM ENVIRONMENT SETUP 4. SET UP I/O 5. PLC SETUP
- 6. INITIALIZE INTERNAL MEMORY
- 7. SET UP TIME
- 8. SET UP SCREEN
- 9. FONT SETUP

Initializing the GLC

5.1 Initialization Screen

Prior to operating this unit, a variety of settings need to be entered/performed. These settings are called the "initial settings". This chapter describes the initial setting items used in the offline mode.



If you transfer your screen design software's System file^{*1}, the GLC operates using that data. If the GLC System file has been correctly setup and transferred, the INITIALIZE settings become unnecessary.

Reference For more information about GLC System files, refer to the **GP-PRO/PBIII for Windows Operation Manual.**

^{*1} This indicates SO file.



5.3 SYSTEM ENVIRONMENT SETUP

GLC environment adjustments are made here. The SYSTEM ENVIRON-MENT SETUP includes the SYSTEM SETUP, SYSTEM DATA AREA, GLOBAL WINDOW SETUP, and CHARACTER STRING DATA SETUP.

1. SYSTEM SETUP



STANDBY MODE TIME (0-255)

To protect the GLC display screen, the GLC is equipped with a screen saver function that automatically erases the screen when no GLC operations have occurred for a period of time. A "0" entered in this field causes a normal display, i.e. the screen is cleared after the GLC's standard default time elapses.

When SYSTEM DATA AREA's (*Reference PLC Connection Manual*) SCREEN DISPLAY OFF^{*1} data is 0000H, and the following operations are *not* performed on the screen for the User's designated period of time, the GLC's current display data is cleared.

- Change Screen
- Touch Screen
- Alarm Display

START TIME (0-255)

This setup determines the start-up time of the GLC. Use this setup to adjust the power up sequence so that the GLC starts up after the PLC.

TOUCH BUZZER SOUND

Setup whether or not the GLC beeps when pressed.

^{*1} When using the Direct Access or the Memory Link formats, the object address becomes +9 or +12, respectively.

PASSWORD SETUP (0-9999)

The password setting is used when changing to the Initialize Memory or Initialize (OFFLINE mode) Screens. The password (*number*) ensures protection of the GLC settings as OFFLINE mode will not be entered inadvertently. Enter the optional number of your choice. If you do not wish to use this setup, enter the default **0**.

DATA TYPE OF SCREEN NO.

This setup controls whether BIN or BCD format numbers are used when making screen changes. Screen numbers 1 to 8999 are available when set up in binary format; screen numbers 1 to 1999 are available when set up in BCD format.

2. SYSTEM AREA SETUP

SYSTEM AREA SETUP is necessary for the PLC to administer the GLC, and prepare the PLC internal Data Memory (DM) and Data Register (D)^{*1}. Use this setup to prepare the desired SYSTEM DATA AREA items. When using the Memory Link format, this setting is unnecessary.

Touch the item number, and when the item is highlighted, it has been selected.



System Area Size

This field displays the total number of words used for the items selected from the SYSTEM AREA SETUP (Write and Read).

When you touch the Confirm key, the SYSTEM AREA CONTENTS screen appears to confirm the selected items.



• The setup shown is enabled only when using the Direct Access format.

• The selected System Area items, as displayed on the screen, become the System Data Area.

When these five items, "Current Screen Number", "Error Status", "Clock Data (Current)", "Change Screen Number", and "Display ON/Off", have been selected, word addresses are assigned to each item, in order, as shown on the next page.

*1 Data Memory (DM) refers to the OMRON PLC; Data Register (D) refers to the Mitsubishi Electric PLC.

SYSTEM AREA CONTE	NTS	SET ESC	7
WORD	WORD		
+0	+10		ттр
+1	+11		
+2	+12		
+3	+13		
+4	+14		
+5	+15		
+6	+16		
+7	+17		
+8	+18		
+9	+19		

Addresses LS16 to LS19 are fixed since they control the Global Window. These addresses cannot be used for any other purpose.

The System DataArea selection process follows this formula [System Data Start Address + n]. For example, if the System Area Start Address was D00200, and the *Change Screen Number* option had been selected—if you refer to the System Area Contents screen displayed above—because *Change Screen Number*'s address is pegged at +6, its word address would be D00200+6=D00206 and be assigned to D00206.

Reference For more information on LS Areas 16 to 19, refer to the GP-PRO/PBIII PLC Connection Manual (included in the screen editor software package).

3. GLOBAL WINDOW SETUP

The GLC unit can display one *Global Window* and two *Local Windows* at any one time. The Global Window is common to all the display screens. The Local Window displays exclusively on the corresponding base screen. The GLOBAL WINDOW SETUP is described here.

GLOBAL WINDOW

There are two options here: Use and Do Not Use. Selecting Use makes the following options available.



GLOBAL ACCESS WINDOW

Setup the Global REGISTRATION NO. and the WINDOW LOCATION as *Direct* or *Indirect* values. When set as Direct, the REGISTRATION NO. and WIN-DOW LOCATION selections are fixed to the values setup here. When set to Indirect, the WINDOW REG. NO. word address, as prepared in the System Area, is variable—which means it can have the REGISTRATION NO. *written* to it—and as a result, multiple window screens can be used as Global

Chapter 5 - Initializing the GLC

windows. Using this same method, adjust the Global window position, by writing the X,Y coordinates to the SYSTEM AREA's WINDOW LOCA-TION word addresses.

DATA FORMAT

Setup whether the REGISTRATION NO. and the WINDOW LOCATION values are inputted as BIN or BCD numbers. This field affects only direct values.

REGISTRATION NO. (1-256)

Setup the Window Screen Number used by the Global Window. This field is applicable only when the GLOBAL WINDOW ACCESS is set to Indirect.

WINDOW LOCATION

Setup for the Global WINDOW LOCATION. This field is applicable only when the GLOBAL WINDOW ACCESS is set to Indirect.

4. CHARACTER STRING DATA SETUP

Character String Data ordering varies from manufacturer to manufacturer. Setup the Character String Data order here to match the corresponding PLC.

CHARACTER STRING DATA SETUP SET ES	sc)
CHAR. STRING DATA MODE 1	



• Setup the CHARACTER STRING DATA MODE to match the PLC type. Device type and Tag settings are unavailable.

Find the data storage order for your PLC in the table, next page, and setup the CHARACTER STRING DATA MODE.

- (I) Data Device Storage Order
- (II) Internal Word Byte LH/HL Storage Order
- (III) Internal Double-word Word LH/HL Storage Order

l) Data Device Storage Order	II) Internal Word, Byte LH/HL Storage Order	III) Double-word Internal Word LH/HL Storage Order	Character String Data Mode
Storage	LH order	LH order	4
data		HL order	2
	HL order	LH order	5
		HL order	1
Storage	LH order	LH order	6
Trom End Data		HL order	7
	HL order	LH order	8
		HL order	3

CHARACTER STRING DATA MODE List

I) Data Device Storage Order

E.g.	Characters	A B	C D	E F (GН
		1	2	3	4

• Storage from Start Data

υ	
0	D100
0	D101
3	D102
٩	D103

Storage from End Data

4	D100
3	D101
Ø	D102
0	D103

II) Word Byte LH/HL Order

E.g.	Characters	A B C D
-		1234

•	16	bit Device LH Orde	r
---	----	--------------------	---

2	1	D100
4	3	D101

• 32 bit Device LH Order

 ②
 ①
 ④
 ③
 D100

•]	6 bit Devic	e HL Order	
	0	2	D100

3 ④ D101	0	0	D100
	3	4	D101

• 32 bit Device HL Order

 ①
 ②
 ③
 ④
 D100

Chapter 5 - Initializing the GLC

III) Double-word Word LH/HL Order

E.g. Characters	"A B	CD	ΕF	GН	IJ"
	1	2	3	4	5

• 16 bit Device HL Order

2	D100
0	D101
4	D102
3	D103
5	D104

• 16 bit Device LH Order

0	D100
\bigcirc	D101
3	D102
4	D103
S	D104

E.g. Characters "A B C D E F G H I J K L M N O P Q R S T" ① ② ③ ④ ⑤ ⑦ ⑧ ⑨ ⑩

• 32 bit Device LH Order

2	0	D100
4	3	D101
6	5	D102
8	\bigcirc	D103
10	9	D104

• 32 bit Device HL Order

1	2	D100
3	4	D101
5	6	D102
Ø	8	D103
9	10	D104



Relationship between K-tag Write Character Value and PLC Device **16 bit Devices**

GLC stores the character string from the start, as groups of 2, into1 PLC Device.

When there are nine characters, they are arranged as shown below.



1 2 3 4 5 6 7 8 9 Null

When the characters do not divide into 2 evenly, NULL is added at the end.

32 bit Devices

GLC stores the character string from the start, as groups of 4, into 1 PLC Device.

When there are nine characters, they are arranged as shown below.

1 2 3 4 5 6 7 8 9 Null



5.4 SET UP I/O

This section describes the communication setup with the host PLC and the setup for any peripheral equipment. The SET UP I/O menu includes the SET UP SIO, SET UP PRINTER, SET UP TOUCH PANEL, and COMMUNICATION SETUP menus.

1. SET UP SIO

This menu runs the settings related to PLC communication. Be sure to match the settings listed below with the SIO setup on the PLC host.

Reference GP-PRO/PB III for Windows PLC Connection Manual

SET UP SIO	SET ESC
COMMUNICATION RATE	19200
DATA LENGTH	7/2
PARITY	EVEN
CONTROL	ER-CNTRL
COMMUNICATION INTERFACE	RS232C

COMMUNICATION RATE

The COMMUNICATION RATE (baud rate) is the data communication speed, measured in bits per second (bps), between the GLC and PLC. Match the COMMUNI-CATION RATE values in both the PLC and GLC. Depending on the rate selected, certain PLCs may not be able to be used.

DATA LENGTH

For data communications, the DATA LENGTH must be set up as 7-bit or 8-bit data.

STOP BIT

Set up the STOP BIT as either a 1-bit or 2-bit value.

PARITY

Set up whether no parity check, or an odd or even number parity check will take place during communication.

CONTROL

Data flow CONTROL prevents the overflow of data sent back and forth. Select either X-CNTRL or ER-CNTRL.

COMMUNICATION FORMAT

Select one of the following options for the communication format: RS-232C, RS-422 (4 lines), or RS-422 (2 lines).



When using an RS422 cable and the Memory Link format, be sure to select the 4-line option.

2. SET UP TOUCH PANEL

Touch operation, Force Reset setup, and Display Device adjustments are made here.



TOUCH OPERATION MODE

Designates either One Point, Two Point or No Slide. When No Slide is selected, dragging one's finger across the touch screen will elicit no screen response, and only individually selected points will register.

FORCE RESET

Set up whether or not FORCE RESET operation is enabled.

Steps to run FORCE RESET

While holding down the bottom right corner (1) of the screen, touch the upper right corner (2). At the same time, touch the bottom left corner (3) to enter the FORCE RESET Operation. To activate Reset, touch the **RESET** button, to transfer to OFFLINE Mode, touch **OFFLINE**.





FORCE RESET can occur during either RUN mode or OFFLINE mode.



- The FORCE RESET mode cannot be entered while the GLC is starting up.
- Entering FORCE RESET is possible even when RUN operations (between PLC and GLC communication) are not being performed.

CONTRAST ADJUSTMENT

When contrast control is designated as effective, contrast can be adjusted via touch input.

While pressing the screen's right upper corner (1), press the left upper corner (2). Then, the contrast control bar will appear on the bottom of the screen. According to the contrast level you touch, the screen's contrast will change.





- This example is of the GLC100-SC41-24V. When using the GLC100-LG41-24V, the contrast level display will become opposite, i.e. the brightest level is the rightmost.
- To exit the contrast control mode, touch anywhere other than the contrast control bar displayed on the bottom of the screen.
- Until the GLC start up procedure completes, this mode cannot be used.
- Contrast control can be performed in the RUN (between PLC and GLC communication) mode.

BRIGHTNESS ADJUSTMENT

When set to ON, BRIGHTNESS ADJUSTMENTs can be accomplished through touch input.

Touch the bottom left corner (2) of the screen while holding down the bottom right corner (1) to enter BRIGHTNESS ADJUSTMENT mode. Touch the left-side of the bar to brighten the display; touch the right-side of the bar to dim the display.





- BRIGHTNESS ADJUSTMENT mode cannot be entered while waiting for GLC to start up.
- BRIGHTNESS ADJUSTMENTs can be made even during RUN mode (PLC<-->GLC communication).

LCD SETTINGS (only for GLC100-LG41-24V)

When the LCD display status is designated as reverse, the screen will be displayed in the reversed color. Use the following steps:

- 1. Touch [LCD SETTINGS].
- 2. Change the LCD status from [NORMAL] to [REVERSE], and then, touch the [SET] key.
- 3. The screen will be displayed in the reversed color and will return to the previous screen.



3. COMMUNICATION SETUP

These fields set *when* an error message is reported after a GLC<—>PLC communication error is detected. This ensures an error has actually taken place and not just slight breaks in communication or slowness in processing data on one side or the other.

COMMUNICATION SETUP	SET	ESC
RECEIVE TIMEOUT (1-127)	10	SEC
RETRY COUNT (0-255)	2	

RECEIVE TIMEOUT

Set up how long the GLC unit will wait when there is nothing being sent to it. (This is the *Timeout Time*.) However, if there is no cable connected up, then regardless of the time set up here, the Timeout value is 1 second. The default value is 10 seconds.



When a value of over 30 seconds is set here, and a screen is transferred from the PC while a PLC Communication Time error has occurred, an error may also appear on the PC side.

RETRY COUNT

This value designates the number of times the GLC retries sending a command before it displays an error messages as a PLC communication error. The default value is 2.

If communication cannot be performed even after trying the number of times designated here, the GLC displays an error message.

Even when an error message is displayed, the GLC continues to send the command until it is received normally.

5.5 PLC SETUP

Here, the settings related to the system data area and controller are performed. [SET UP OPERATION SURROUNDINGS] includes the [SET UP OPERATION SURROUNDINGS] and [CONTROLLER SETTING].

1. SET UP OPERATION SURROUNDINGS



Enter the PLC System Data Area and the Unit Number settings here.

This setup is only necessary when using the Direct Access format.

SET UP OPERATION SURROUNDI	NGSSET
SYSTEM AREA START DEV	D
START ADR	0
UNIT No.	0
SYSTEM AREA READ SIZE	0

SYSTEM AREA — STARTING DEVICE/STARTING ADDRESS

Setup the PLC's Data Register (D), Data Memory (DM), etc. allotted by the STARTING ADDRESS OF SYSTEM DATA AREA.



When a PLC, to which multiple number of devices are available to allocate, has been selected, touch the Starting Device input area, and a keyboard will appear.

UNIT NO.

Set up the PLC UNIT number here. Make sure it matches the one set up in the PLC.

SYSTEM AREA—READING AREA SIZE (0-256)

When using a Block Display Trend Graph, setup the Reading Area Size (in word units) to match the Trend Graph's data size. Setup when you wish to allocate the Reading Area in the PLC Data Register (D), or Data Memory (DM).



If you are not using the Reading Area, leave the 0 default values intact. High Speed Communication can be performed as a result.

Controller Setup 2.

Here, the settings related to the controller are performed. [CONTROLLER SETTING] includes [CONTROLLER SETTING] and [CONTROLLER DIAGNOSIS] and [I/O Driver Settings].



This section explains how to perform [CONNTROLLER SETTING].



TReference For the explanations about controller self-diagnosis and I/O driver settings, refer to the Pro-Control User's Manual (included in the Pro-Control Editor package).



• [CONTROLLER SETTING] can also be performed via the Pro-Control **Editor software.**

Reference Pro-Control Editor Operation Manual (included in the Pro-Control Editor software package).

Data set up via the Pro-Control Editor or GLC's CONTROLLER SETTING is written in the GLC's nonvolatile memory. Although the default value has been entered in the CONTROLLER SETTING's each item, be sure to alter them according to the usage purposes.



TARGET SCAN TIME (10 - 2000ms)

Here, the total time required by the controller and the GP is set up. The controller time represents the time required to perform an I/O read, the logic program operation, and an I/O write. The setup range is from 10 to 2000ms. When entering the TARGET SCAN TIME setting, the PERCENT ALLOCATION becomes 50%.

PERCENT ALLOCATION (0 - 50%)

Here, the controller time's ratio to the total scan time is designated. The setup range is from 0 to 50%. When PERCENT ALLOCATION is used, the TARGET SCAN TIME is disabled.

CONTROLLER STATE

Designates the operation mode (START, STOP or DEFAULT) used when the GLC's power is turned ON.

STOP ON MINOR FAULT

Designates whether logic program operation is continued or stopped when a minor problem occurs during controller use. To continue RUN operation, select "ON" and to stop operation when a problem occurs, select "OFF"

Reference Pro-Control Editor Online Help feature

WATCHDOG TIMER (100 - 3000ms)

Designates the watchdog time setting usual during controller and GLC operation time (100 to 3000ms). Enter a value in 100ms units. Entering "0" disables the watchdog function.

5.6 INITIALIZE INTERNAL MEMORY

This command erases all the GLC screen data and initializes the GLC's SRAM.



- You cannot cancel the Initialization procedure after pressing the Start key.
- Initialization does not erase the SYSTEM SET UP, the SIO protocol, or the internal clock settings.



Enter the common password **1101**, or the password entered in the SYSTEM SET UP screen.

Memory initialization will take approximately 10 to 15 seconds.

5.7 SET UP TIME

SET UP TIME
PRESENT TIME
'Y.M.D. :
TIME SET UP
' Y. M. D. :

Sets the GLC's internal clock.

SET UP TIME

Enter date and time corrections to the date and time displayed in the PRESENT TIME.



• The GLC's internal clock has a slight error. At normal operating temperatures and conditions, with the GLC operating from its lithium battery, the degree of error is 65 seconds per month. Variations in operating conditions and battery life can cause this error to vary from +90 to -380 seconds per month. For systems where this degree of error will be a problem, the user should be sure to monitor this error and make adjustments when required.

• Year, month, day, hour, and minute data can be written to the system data area's clock data, in the same manner as the OFFLINE mode.

5.8 SET UP SCREEN

The initial screen display upon powering up, the character size when in RUN mode, and other related general screen items are setup here.

SET UP SCREEN	SET ESC
INITIAL SCREEN NO.	В 1
ALARM MESSAGE V SIZE	1
H SIZE	1
ONLINE ERROR DISPLAY	ON

INITIAL SCREEN NO.

Set up the screen file number that will display first upon powering up. If the BIN option for DATA TYPE OF SCREEN NO in SYSTEM SET UP had been selected, enter a number from 1 to 8999. Or, if BCD was the option set up, then input a number from 1 to 1999.

ALARM MESSAGE

Set up the character size of the ALARM MESSAGE when the Alarm Bulletin is activated.



Height 1 Width 1 16×8 pixels

1

Height 2 Width 2 32×16 pixels



Height 4 Width 4 64×32 pixels

ONLINE ERROR DISPLAY

Set up whether or not error messages display during RUN mode.
5.9 SET UP FONT

Here, fonts to be used in the RUN mode will be designated.

FONT SETTING	SET ESC
FONT SETTING	JAPAN
KANJI FONT QUALITY	HIGH

FONT SETTINGS

Designates fonts to be used in the RUN mode. Designate as [JAPAN].

Kanji Character Font Settings

When selecting the high quality font setting, full-sized (2X2 or larger) characters will be displayed as 32X32 dot (high resolution) fonts. When selecting the standard font setting, the 16X16 dot fonts will simply be enlarged.



- This setting is effective only when the [JAPAN] font is selected.
- High quality fonts are applicable for JIS Standard 1. Regardless of the font settings, Standard 2 fonts will be displayed as 16X16 dot fonts.



- 1. GLC RUN Mode
- 2. Troubleshooting
 3. SELF-DIAGNOSIS
- Chapter

6

4. Error Messages

GP RUN Mode and Errors

6.1 GLC RUN Mode

There are two ways of entering the GLC's RUN mode; first, immediately after plugging in the unit's power cord, and the other, from the GLC's OFFLINE mode.

1. After Powering Up the GLC

First, connect the GLC's power cable. After the unit has powered up, the START TIME value, set up in INITIALIZE area's SYSTEM SET UP feature, determines how long the display shown below is shown. If, however, a screen has not been designated in the INITIALIZE area's SET UP SCREEN feature, or if the screen itself does not exist, then this display will remain.



Protocol Name

System Version

2. Via OFFLINE Mode

Touch the MAIN MENU'S RUN selection to start your downloaded "project". The INITIALIZE area's SET UP SCREEN feature designates the first screen that appears in RUN mode, and, after this screen appears, communication with the PLC begins. If the designated screen does not exist, the screen displayed when turning the power ON appears.

	MAIN MENU
	INITIALIZE
	TRANSFER SCREEN DATA
	SELF-DIAGN0SIS
l	RUN
	Э <u> </u>



To enter OFFLINE Mode, simply touch the top left corner of the GLC's screen within 10 seconds after connecting the GLC's power cord.

E.g. After powering up the GLC, the initial screen that appears is equipped with a built-in (invisible) switch in the top left corner. Touch this switch to change the GLC from RUN to OFFLINE mode.



6.2 Troubleshooting

Here, the means to locate and remove causes of problems are explained. It is assumed that the problems described here are caused by the GLC unit's problems, not host (PLC)'s. If problems caused by the host (PLC) occur, please refer to the host (PLC)'s manual.

1. Possible Types of Trouble

Shown below are some problems that may occur while using this unit.

(A) No Display

The screen will not display even when the unit is powered On. Also, during RUN mode, the screen disappears.

(B) No GLC/HOST Communication

The GLC unit cannot extract data from the host. An error message may appear on the screen as a result.

References 6.4 Error Messages

(C) Touch Panel Does Not Respond

The touch panel does not react when pressed, or the reaction time is very slow.

(D) OFFLINE Displays During RUN Mode

Enters OFFLINE mode unexpectedly during operation. Enters OF-FLINE mode when the power is turned ON.

(E) The Logic Program Does Not Operate

The desired program does not appear on the GLC's screen. The control memory's SRAM backup data is not preserved.

For (A), (B) and (C) problems, see the following pages' troubleshooting tables. For the fourth problem (D), a SYSTEM ERROR may have developed while displaying the OFFLINE mode screen.^{*1}

References 6.4.2 Error Message Details

For problem (E) possible cause(s) and countermeasure(s), refer to

References 6.2.2 (D) "Logic Program Does not Operate" Checklist

*1 If the user touches the top left corner of the screen within 10 seconds after powering up the GLC, the change to the OFFLINE screen is not an error.



It is assumed that the problems described in this chapter are caused by the GLC unit's problems, not host (PLC)'s. If problems caused by the host (PLC) occur, please refer to the host (PLC)'s manual.



2. When Screen Does Not Appear

If no screen appears when the unit's power is turned on, or if a screen disappears during operation, locate the problem cause(s) using the following flow chart and take appropriate countermeasure(s).





*1 To display the offline screen, turn the power off, and on again. Then, touch the screen's left upper corner within 10 seconds.

Chapter 6 - GLC RUN and Errors



^{*1} When performing the internal FEPROM check via the self-diagnosis function, all the screen data will be erased. Prior to performing this check, be sure to confirm that the screen data has been all backed up.

3. When No Communication with PLC is Performed

If the communication between the GLC and PLC is not performed, locate its cause(s) via the following flowchart and take appropriate countermeasure(s). Also, if an error message appears on the GLC unit's screen, check the error code and take appropriate countermeasure(s).









To perform self-diagnosis (communication check), special tools (and cables) are required.

For the detailed information about self-diagnosis and these tools:

Reference 6.3 SELF-DIAGNOSIS

4. When Touch Panel Does Not Work

If the touch panel does not work even when you touch it, locate its cause(s) according to the following flowchart and take appropriate countermeasure(s).



5. When Logic Program Does Not Operate

This section describes control function errors.

There are the following three control function errors:

- I/O unit input error
- I/O unit output error
- Program operation error

Program error causes and their countermeasures are as follows.

For the I/O unit errors:

Reference Pro-Control User Manual (included in the Pro-Control Editor software package)

Program Operation Errors

Problem	Possible cause	Countermeasures	
The control memory's	Battery problem	Replace the unit.	
not exist.	Memory problem	Replace the unit.	
Abnormal program	Incorrect program transfer. Memory has a program backup area. The program may not have been transferred from there to the operation area.	Use Pro-Control Editor to restart the control function. <i>Reference</i> Pro-Control Editor User's Manual	
operation	When switching output data's RUN and STOP operations, the backup data clear control function is enabled.	Disable this function.	
After entering RUN mode, the GLC enters STOP mode again.	Abnormal command execution or major problem may have occurred.	Connect the program. Check the system variable "#FaultCode."	

6.3 SELF-DIAGNOSIS

The GLC unit is equipped to check its own System and Interface for any problems. Use it to help diagnose any problems.

1. GLC SELF-DIAGNOSIS Item List



DISPLAY PATTERN

Checks all the figures and tiling patterns.

TOUCH PANEL

Checks each GLC touch panel square.

INTERNAL FEPROM CHECKSUM

Checks the System and Protocol of the GLC Internal Memory (FEPROM).

FRAME BUFFER

Checks the internal display memory (Frame Buffer).

TOOL CONNECTOR LOOP BACK^{*1}

Checks the Tool Connector control lines and send/receive lines.

INPUT PORT

Checks the Input Port. (For Digital's maintenance use only)

SIO CHECK^{*1}

Checks the RS-232C and RS-422 send/receive lines.

1 These SELF-DIAGNOSIS items marked with an asterisk () require special tools. Please prepare the required tool (cable) for each test.

2. **SELF-DIAGNOSIS** - Details

This section explains the contents of SELF-DIAGNOSIS.



References For information on how to operate the Screen, refer to Chapter 4, OFFLINE Mode.



References For information about how to set up items conneced to the GLC, refer to Chapter 3, Installation and Wiring.

DISPLAY PATTERN

Used when the buzzer will not sound and when the device contents will not display correctly to check the drawing function. It does this by running checks on the various screen pattern displays (9 screens) and on the ON/OFF Display. When the ON/OFF Display is checked, the Buzzer ON/OFF check is run simultaneously. If everything is normal, **OK** displays; if there is a problem, **NG** displays.

TOUCH PANEL

Touch Panel check. Checks if each touch cell highlights when pressed.

INTERNAL FEPROM CHECKSUM (System & Protocol)

The Internal FEPROM System and Protocol check searches for any problems that may arise during operations. When running the check, the screen will change as follows.



When the FEPROM is normal, **OK** displays; if there is a problem, an error message appears. This check does not erase the System or Protocol.

FRAME BUFFER

The Frame Buffer (display memory) Check looks for any display problems that may develop. When everything is normal, OK displays; when there is a problem, an error message displays.

Chapter 6 - GLC RUN and Errors

TOOL CONNECTOR LOOP BACK

Use the Tool Connector Control line and Send/Receive line check when the GLC cannot send and receive data from the PC. To run the check, connecting a *Tool Connector Check Loop Back Cable* (Dsub9 pin, pin-side) mounted to the *Data Transfer Cable* (provided in the GP-PRO/PBIII for Windows software package) is necessary.

When everything is normal, **OK** displays; when there is a problem, an error message displays.



INPUT PORT

Used for Digital's maintenance check.

SIO CHECK

Checks the RS-232C and RS-422 SIO lines for areas where communication problems develop. In the menu, select which check to run. To run the check, connecting the SIO cable is necessary. If all is normal, **OK** displays; if there is a problem, an error message appears.

The SIO cable wiring is as shown below. (RS-232C, RS-422 common)



6.4 Error Messages

This section explains the messages that appear when an error has occurred in the GLC unit during RUN mode. The origin of the problem behind each error message is explained with appropriate ways of disposing of the error. After a problem has been solved, unplug the GLC's power cord and then reattach it. *(Only the latest error message will appear on the GLC screen)*

1. Error Message List

The error messages listed below appear on the GLC unit. Instructions on how to find and solve problems causing these error messages are explained on the following pages.

- SYSTEM ERROR
- ILLEGAL ADDRESS IN SCREEN DATA
- UNSUPPORTED TAG IN SCREEN DATA
- PLC NOT CONNECTED (02:FF) and (02:F7)
- PLC NOT RESPONDING (02:FE)
- RECEIVE DATA ERROR (02:FD)
- PLC COM. ERROR
- SCREEN MEMORY DATA IS CORRUPT
- CLOCK SETUP ERROR
- SCREEN TRANSFER ERROR
- SCREEN TAG LIMIT EXCEEDED
- OBJ. PLC HAS NOT BEEN SETUP



- If there are more than one error, only the latest error message will appear.
- If any error code other than above error codes, the error occurred in the controller.

Reference Pro-Control User Manual (included in the Pro-Control Editor package)

2. Error Message Details

SYSTEM ERROR

Indicates a fault in the basic operations of the GLC. Following the error message, an error code, as shown, will appear. Report the error number and details on how the error developed to your local GLC distributor.

(Ex. 1) • SYSTEM ERROR (03 : x x)

Displays when an unrecoverable error occres during data transfer from a PC.



(Ex. 2) • SYSTEM ERROR (x x x : x x x : x x x)

Displays when an unrecoverable error occurs during data transfer.



- Check if the GLC's Power Cord and the Input signal line have been wired incorrectly.
- Check that the FG line has been grounded correctly, according to standards.
- Re-send the screen data from the PC to the GLC.
- If other types of communication errors have also occurred, try to correct those problems also.

References This chapter's RECEIVE DATA ERROR, PLC COM. ERROR

If the above mentioned methods do not solve the problem, please contact your local GLC distributor.

• When OFFLINE mode displays during in RUN mode

When the GLC changes to OFFLINE mode without the user first pressing the screen, there is a possibility that the screen data has been damaged. In this case, after the SYSTEM ERROR displays, the screen automatically reverts to OFFLINE mode after about 10 seconds. Run the INITIALIZE MEMORY command and transfer the Pro-control Editor's screen data again from your PC.

ILLEGAL ADDRESS IN SCREEN DATA

Caused by addresses overlapping.

Following the error message, error codes, as listed below, appear. If the error cannot be fixed, please report the error code and details on how the error developed to your local GLC distributor.

ILLEGAL ADDRESS IN SCREEN AREA (00b:XXX:XXX)



Error 1	Error 2	Meaning	
	191	All or part of the T-File ¹ or S-tag	
0C1	192	address range overlap the addresses of System Data Area.	
	193		
	194	All or part of the System Data Area	
0C2	195	range overlap the addresses setup in	
	196	a T-File.'	
	197	All or part of the T-File, or the S-tag	
0C3	198	address range set in an A-file.	
	199		
0C9	19B	All or part of the T-Fil ^{*1} , or the S-tag or K-tag address range overlap the address range set in an A-file.	

Overlapping Addresses Table



• Overlapping addresses, other than the ones mentioned above, can also cause the Illegal Address message.

E.g. When the starting address of the System Data Area is set to 100, and the tag below is setup:

Tag Name/ Part ID No.	Word Address	Tag Format
N1	99	BCD32

Note: The N-tag is set to 32 bits, meaning it uses two word addresses. Since the first address is 99, the second address must be 100. Address 100 is ineligible for use since it has already been used for the System Data Area.

*1 **CREFERENCE** For details about the T-File (trend graph) and A-File (alarm messages), refer to the GP-PRO/PB III for Windows Tag Reference Manual.

Chapter 6 - GLC RUN and Errors

UNSUPPORTED TAG IN SCREEN DATA

This message will appear when there is/are tag(s) that has/have not been supported via the currently used GLC unit. In this case, initialize the memory to check if the tag(s) that are not supported by this unit have been set up, and then, transfer data.

For the detailed information about tags:

Reference: GP-PRO/PBIII for Windows Tag Reference Manual (included in the screen editor software package)

PLC NOT CONNECTED (02:FF) (02:F7)

Displays when communication with the PLC has stopped for over 60 seconds, when there is a transmission timeout error, or when there is excess *noise*. Check the data transfer cable wiring and connect correctly.

PLC NOT RESPONDING (02:FE)

Displays when there is a Reply Timeout Error, or when there is excess noise.

The origin of the problem and the matching solutions are listed in the table below.

PROBLEM	SOLUTION
1. The PLC is not turned ON.	1. Turn On the host's power switch
2. GLC unit INITIALIZE setup (Setup I/O, PLC Setting) is incorrect.	2. Setup the unit correctly and match up with the current host and Communication Cable.
3. The host and GLC powering up process was incorrect.	3. Turn the host's power On first, wait 2~3 seconds, then power up the GLC unit.
4. The Communication Cable was not connected properly.	4. Check the Communication Cable wiring and connect it up properly.

RECEIVE DATA ERROR (02:FD)

This problem arises as a result of one of these three:

- There is a problem in trying to receive the data
- The connected PLC and the PLC setup for the data is different
- Noise

These errors, except for noise, appear when the Communication Cable is pulled out when the GLC unit is On, or when normal communication operations are being run, but the GLC has been powered Off, then back On. To solve the problem, simply begin running transmissions again.

When the error is a result of noise, correct any improper connections.

PLC COM. ERROR

Appears when the address setup for tags exceeds the address range on the host side, etc. Check the Error Number that appears and use the following table to solve the problem.

PLC COM. ERROR (02: x x)

- Error code (see the table below)

- Constant Value

Error#	Origin	Solution
FC	• When using the memory link method: The data format that this unit received was incorrect.	Check the data transferred from the host.
FB	 When using the memory link method: When using the PLC manufactured by Toyota Koki: Addresses used for tags, addresses where trend graph data has been stored, and addresses designated when alarm messages were registered exceed the memory area range (address range error). 	 When using the memory link method: Set the addresses within the system area range (0 to 2047) and transfer the correct command(s). When using the PLC manufactured by Toyota Koki: Set the addresses within the allowable range.
FA	Address range error	Set the addresses within the allowable range.
53	There are too many screen tags, the PLC will not receive data.	Decrease the number of tags on the screen.
51	The tag address, Trend graph data storage address, Alarm message Registry address, and the like, do not exist in the PLC's internal memory.	Setup the addresses in a device range that exists.
Others	The Error Number for each PLC is displayed the indicated PLC manual. Or, report the	ed. Look up the Error Number in error Number to the PLC maker.

SCREEN MEMORY DATA IS CORRUPT

Displays when the checksum of the screen memory data does not match because of a corruption in the screen files.

This error message is followed by error codes. By referring to the error code, you can check the screens that have errors. When a screen file has been corrupted, delete that file, and make a new one (or recall a backup copy if available).

SCREEN MEMORY DATA IS CORRUPT (x x x x : x x x x)

The Screen Number that has an error. (Displays only one per Screen Number.) The number of screens that have errors (Decimal)

CLOCK SETUP ERROR

This message displays when the backup battery for the internal clock is dead. If the battery is incorrectly replaced, the battery may explode. To avoid the danger, please do not replace the battery yourself. When the battery needs a replacement, please consult with your local GLC distributor.

After changing the backup battery, set up the internal clock.

References Chapter 5, Initializing the GLC



• The life span of the backup battery depends on the battery's ambient temperature and the amount of current being charged and used. The table below gives a general indication of how long the battery will last.

Battery Ambient	under 40°C	between	between
Temperature		40 to 50°C	50 to 60°C
Expected Life Span	over 10 yrs.	over 4.1 yrs.	over 1.5 yrs

SCREEN TRANSFER ERROR

Displays when an error occurs in the data transmission from the screen editor to the GLC panel. Check if the cable is connected correctly and try retransmitting the screen data.

SCREEN TAG LIMIT EXCEEDED (max. of 384)

When tags are setup beyond the tag limit, these tags are made invalid. Tags are invalidated from the end tag, in the opposite order in which they were registered. Plus, when tags involve registered Windows and loaded screens, they are invalidated in this order: Window Registry, Load Screen. Further details for when multiple displays are set to one screen:

- 1. Disregard registered windows, starting from the end screen.
- 2. Disregard loaded screens, starting from the end screen.

To correct this problem, reduce the number of tags to within the allowed limit.

OBJ. PLC HAS NOT BEEN SETUP (02:F9)

The host PLC setup in the Editor program (i.e. the .prw file) does not match the PLC in use. Use the Error Code that follows the error message to select the proper PLC type in the GLC and correct the INITIALIZE setup.

OBJ. PLC HAS NOT BEEN SETUP (x x)

The PLC number (*Hexadecimal*) written to the System File

(See next page's Table)

Chapter 6 - GLC RUN and Errors

PLC #	PLC TYPE	PLC #	PLC TYPE
0	SYSMAC C	35	Data Highway Plus
1	MELSEC-AnN(LINK)	36	Remote I/O
2	New Satelite JW	38	Modbus Plus
3	FA500(for GP- PRO/PBIII:FACTORY ACE)	46	Simatic S7-200PPI
4	MICREX-F	4D	MEMORY LINK SIO TYPE
6	TOYOPUC-PC2	4F	PROFIBUS
7	MEWNET-FP	52	Simatic S7-300/400 MPI
8	HIDIC-S10α	55	Simatic S7 via 3964/RK512
9	Memocon SC	63	FA500 1:n(for GP-PRO/PBIII: FACTORY ACE 1:n)
В	MELSEC-AnA(LINK)	66	GE FANUC 90SNP
С	KOSTAC SR21/22	67	HIZAC EC
D	SYSMAC CV	68	IDIC 1
E	PROSEC EX2000	69	IDIC 2
10	HIZAC H	6A	IDIC 3
11	MELSEC-FX	6B	FANUC Power Mate
12	MELSEC-F2	6C	MICRO3
13	HIDIC S10-2aH	6D	KEYENCE
14	KOSTAC-SG8	6E	SELMART
15	PROSEC-T	6F	FLEX-PC(CPU)
18	FLEX-PC	71	MELSEC-A ETHERNET
19	Panadac 7000	75	PROGIC 8
1B	TC200	76	GL120/130

1. Regular Cleaning

2. Changing the Backlight

Chapter

7

Maintenance

7.1 Regular Cleaning

1. Cleaning the Display

When the surface or the frame of the display gets dirty, soak a soft cloth in water with a neutral detergent, wring the cloth tightly, and wipe the display.



- Do not use paint thinner, organic solvents, or a strong acid compound to clean the unit.
- Do not use hard or pointed objects to operate the touch-screen panel, since it can damage the panel surface.

Installaiton Gasket Check/ Replacement 2.

The installation gasket protects the GLC and improves its water resistance. For instructions on installing the GLC's gasket, refer to

Reference Chapter 3 "Installation and Wiring"



A gasket which has been used for a long period of time may have scratches or dirt on it, and could have lost much of its *Important* water resistance. Be sure to change the gasket periodically (or when scratches or dirt become visible).

- Ribs E Important Ð K Seam
- Attaching the Installation Gasket
 - 1) Each of the GLC's corners has 4 ribs that hold the installation gasket in place. Push the gasket into the side of the GLC, so that it is held by all 4 ribs.
 - The gasket is flexible, but not elastic, and may tear if stretched too far. Do not stretch the gasket around the ribs, only push.
 - Be sure the gasket's seam is not inserted into any of the unit's corners, only in the straight sections of the groove. Inserting it into a corner may lead to its eventually tearing.

Chapter 7 - Maintenance



Be sure to insert the gasket into the groove so that the long side is vertical.

- Abbrox, 1, 5mm
 - 2) Insert the gasket into the GLC's three remaining corners, as shown in step 1.

 The gasket must be inserted correctly into the groove for the GLC's moisture resistance to be equivalent to IP65f.

Important

• The upper surface of the gasket should extend approximately 1.5mm out from the groove. Be sure to check that the gasket is correctly inserted before installing the GLC into a panel.

7.2 Changing the Backlight

This section describes how to replace the backlight.

•	To prevent an electric shock, be sure the GLC's power Cord is unplugged from the power outlet prior to changing the Backlight.
•	When the power has just been turned OFF, the unit and Backlight are still very hot. Be sure to use gloves to prevent burns.
•	The backlight is very fragile. Do not touch the glass tube directly or try to remove its power cord. If the glass tube breaks you may be injured.



Use the following table to check that you have ordered the correct backlight.

GLC	Backlight Model
GLC100-LG41-24V	
GLC100-SC41-24V	GP370-BL00-IVIS

Use the following steps to change the Backlight. Be sure to use gloves.

- 1) Unplug the GLC's power cord from the power supply. Then, remove the GLC's power cord terminals from the power terminal block. (Fig. A)
- 2) Unscrew the GLC's two (2) top face attachment screws. (Fig. B)
- 3) Turn the unit so the display surface is facing down. At this time, be sure not to scratch or damage the display surface.
- 4) Insert a screwdriver into the hole located on the GLC unit's side face to open the case. (Fig. C)
- 5) Open the unit and detach the backlight connector (Fig. D) At this time, do not remove the inside cover. (Fig. E)
- 6) Push the backlight's Lock Tab to the right to free the backlight, then pull it upwards and out of the unit. (Fig. F)

Chapter 7 - Maintenance



DO NOT click the Lock Tab to the left with the backlight removed. Otherwise, the Lock Tab can be broken.

- 8. Insert the new backlight and slide it into its slot until the Lock Tab can be clicked into place, and Attach the new backlight's Power Connector to the inverter board.
- 9. To replace the GLC's rear cover, insert the cover's guide tabs into the case's guide slots and close the cover. Be sure that the Rear Cover Connector and the Front Unit Connector are correctly aligned. (Fig. G)



