



SCIGATE AUTOMATION (S) PTE LTD

No. 1 Bukit Batok Street 22 #01-01 Singapore 659592

Tel: (65) 6561 0488

Fax: (65) 6562 0588

Email: sales@scigate.com.sg

Web: www.scigate.com.sg

Business Hours: Monday - Friday 8.30am - 6.15pm

Device/PLC Connection Manuals



About the Device/PLC Connection Manuals

Prior to reading these manuals and setting up your device, be sure to read the "Important: Prior to reading the Device/PLC Connection manual" information. Also, be sure to download the "Preface for Trademark Rights, List of Units Supported, How to Read Manuals and Documentation Conventions" PDF file. Furthermore, be sure to keep all manual-related data in a safe, easy-to-find location.

Toshiba Schneider Inverter Connectable Devices

The following tables list the devices that can be connected and used with the GP.

■ Inverter List

Manufacturer	Series Name	CPU	Comments	Device Type in Screen Editor
Toshiba Schneider Inverter	VF-S9	VFS9□-□□□□□□-□□- A□□ *1		Toshiba Schneider Inverter
	VF-nC1	VFNC1□-□□□□□□-□- A□□		
	VF-S11	VFS11□-□□□□□□□□- □□-□□□		
	VF-A7	VFA7-□□□□□□□-□□□		
	VF-P7	VFP7-□□□□□□-□□□		

*1 "□" will vary depending on the CPU model. For details, refer to your inverter unit's manual.