

SP5000 Series and FP5000 Series ATEX/IECEX Instruction Guide www.pro-face.com

Concerning the use of SP5000 Series and FP5000 Series for applications in potentially explosive atmospheres (Zones 2/22)

Digital Electronics Corporation
4-4-9 Kitahama, Chuo-Ku, Osaka-Shi,
Osaka, 541-0041 JAPAN

Type examination certificate: INERIS 15ATEX3007X
IECEX Certificate of Conformity: IECEX INE15.0018X

SAFETY INSTRUCTIONS

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a "Danger" or "Warning" safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in death or serious injury.**



* N H A 6 8 3 5 6 0 2 *

The information in this document is subject to change without notice.

Copyright © 2016/5 Digital Electronics Corporation

All Rights Reserved.

NHA68356 02

Printed in

**SCIENCE
GATE**
Your Automation Partner



SCIGATE AUTOMATION (S) PTE LTD

No.1 Bukit Batok Street 22 #01-01 Singapore 659592

Tel: (65) 6561 0488

Fax: (65) 6562 0588

Email: sales@scigate.com.sg

Web: www.scigate.com.sg

Business Hours: Monday - Friday 8.30am - 6.15pm

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.


NOTICE

NOTICE is used to address practices not related to physical injury.

PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Digital Electronics Corporation for any consequences arising out of the use of this material. A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

SCOPE

This present document applies when the SP5000 Series and FP5000 Series bears  marking and provides important information when used in hazardous areas. This documentation has to be kept and always refer to those instructions for installation, operation, maintenance or evolution of your system.

You can download this instruction guide at www.pro-face.com.

If any translation is needed, you can contact your local Pro-face support or sales center.

SP5000 Series and FP5000 Series are only supplied with 12...24 Vdc

Relevant Standards

These terminals have been manufactured in accordance with:

- Standard EN 60079-0 (2012) + A11 (2013) and IEC 60079-0 Ed6.0 (2011): Explosive atmospheres - Part 0: Equipment - General requirements.
- Standard EN 60079-15 (2010) and IEC 60079-15 Ed4.0 (2010): Explosive atmospheres - Part 15: Equipment protection by type of protection “n”.
- Standard EN 60079-31 (2009) and IEC 60079-31 Ed2.0 (2013): Explosive atmospheres - Part 31: Equipment dust ignition protection by enclosure “t”.



DANGER

POTENTIAL FOR EXPLOSION


Install, use, and maintain these modules in accordance with:

- Standard IEC 60079-14 Ed4 (2007): Explosive atmospheres - Part 14: Electrical installations design, selection and erection.
- Standard EN 60079-17 (2007): Inspection and maintenance of electrical installations in hazardous areas.
- Standard EN 61241-14 (2004): Electrical apparatus for use in the presence of combustible dust, Part 14: Electrical apparatus protected by enclosures. Selection, installation and maintenance.
- Edicts, by-laws, laws, directives, circulars, standards, regulations and any other document relating to where the apparatus is installed.

Failure to follow these instructions will result in death or serious injury.

Permitted zones of application

Refer to the section "Markings" to get information about the permitted zones of protection and the types of protection.

- SP5000 Series and FP5000 Series installed in zones 2/22 hazardous areas must be certified and bear the  marking
- Ensure with the marking that the terminals are compatible with the conditions permitted for the hazardous area at the site where it is being used.

Installation, Operation and Maintenance

Make sure you follow all the recommendations in the SP5000 Series and FP5000 Series user manual and additionally those listed below.



DANGER

POTENTIAL FOR EXPLOSION

- Confirm that the location is free from explosively hazardous gases or dust before connecting or disconnecting equipment, replacing or wiring modules.
- Make sure that the ambient temperature in protective enclosure never exceeds 60 °C.
- Confirm each interface (COM, Ethernet, USB, power line, ...) has been securely locked.
- Confirm that any USB cable has been attached with its appropriate clamp.
- Install the certified equipment in a protective enclosure providing at least IP54 protection when applied in zone 2 environments and IP6x when applied in zone 22 environments. This protective enclosure must be certified for hazardous areas zone 2 or 22 and shall not be opened when an explosive atmosphere is present.
- Confirm that the power supply has been turned OFF before disconnecting, replacing or wiring modules.
- Ensure that ground at power supply is properly connected.
- Do not use equipment that has been damaged.
- Implement method to avoid risk of electrostatic discharge at using zone 2 and 22 areas. See the details at Note.
- Do not expose the terminal to direct sunlight.
- Do not allow layers of dust to form on SP5000 Series and FP5000 Series: it should be cleaned regularly.


Failure to follow these instructions will result in death or serious injury.

NOTE: SP5000 Series and FP5000 Series have risk of electrostatic discharge. If the product is operating in zone 2/22 areas, the following instructions must be applied:

- Use non-conductive gloves (e.g. Electrosoft Latex Gloves by Honeywell Safety) made of leather, plastic or rubber whose surface resistance is more than 1 GΩ at 23 ± 2 °C and 50 ± 5 % relative humidity.
- Use a non-conductive touch pen (e.g. CA7-TTPEN/ALL-01 by Pro-face) made of plastic material whose surface resistance is more than 1 GΩ at 23 ± 2 °C and 50 ± 5 % relative humidity to all terminals.

Markings


ATEX and IECEx markings, applied to the SP5000 Series and FP5000 Series are as follows:

Models	Marking
PFXSP5400WAD PFXSP5500TPD PFXSP5500WAD PFXSP5600TPD PFXSP5660TPD PFXSP5600WAD PFXSP5700TPD PFXSP5B10 PFXSP5B40 PFXFP5600TPD PFXFP5700TPD PFXZCDEUPF1 PFXZCDEUCA1	<p>Digital Electronics Corporation 541-0041 Osaka Japan</p>  <p>INERIS 15ATEX3007X IECEx INE 15.0018X II 3 G D Ex nA nC IIC T4 Gc Ex tc IIIC T135°C Dc</p> <p>Tamb: 0°C to +60°C</p> <p>WARNING - Do not disconnect when circuit is live. - Potential electrostatic charging hazard (see instructions).</p>
<p>NOTE: Other required elements such as product reference, serial number and date code of manufacture are already marked on products.</p>	




EU DECLARATION OF CONFORMITY

We: Schneider Electric Industries SAS
35 rue Joseph Monier
Rueil Malmaison 92506 - France

Hereby declare under our own responsibility that the products:

Trademark	 Pro-face <small>by Schneider Electric</small>
Product, Type	Human Machine Interface SP5000 Series: PFXSP5500TPD, PFXSP5600TPD, PFXSP5660TPD, PFXSP5700TPD, PFXSP5400WAD PFXSP5500WAD, PFXSP5600WAD, PFXSP5B10, PFXSP5B40, PFXZCDEUPF1, PFXZCDEUCA1 FP5000 Series: PFXFP5600TPD, PFXFP5700TPD Includes models with additional alphanumeric characters at the end of the model number.
List of reference and options	See the SP5000 Series and FP5000 Series ATEX/IECEX Instruction Guide.

Are in conformity with the requirements of the following directives and conformity was checked in accordance with the following standards.

Directive	Harmonized standard / Notified body reference
ATEX Directive 2014/34/EU	EN 60079-0: 2012 / A11: 2013, EN 60079-15: 2010, EN 60079-31: 2009
(*) According to art 41.2, certificates issued under Directive 94/9/EC shall be valid under this directive.	EC Type examination certificate: INERIS 15ATEX3007X (*) and IECEx INE 15.0018X    II 3 G D Ex nA nC IIC T4 Gc Ex tc IIIC T135°C Dc Tamb: 0°C to +60°C By INERIS: Parc Technologique ALATA, 60550 Verneuil en Halatte - France

Subject to correct installation, maintenance and use conforming to its intended purpose, to the applicable regulations and standards, to the supplier's instructions and to accepted rules of the art. This declaration becomes invalid in the case of any modification to the products not authorized by us. Compliance with the ATEX Directives will require the application of ATEX guide giving requirements, details and advices for installation of products used. The guides are available on www.pro-face.com

Issued at Carros - FRANCE: April 20th, 2016

Name: Alain BERNERD
Industrial Control & Drives
Customer Satisfaction & Quality
Vice President

