

Baying Free Standing Cubicles (Unidrive SP size 9, 6 pulse)

Figure 1-1 Preparation for baying the size 9 free standing drive (slave and master)





Figure 1-2 Location of the rectifier status connectors









0471-0061-02

Figure 1-3 Baying of cubicles




- 1. Push the two cubicles together
- Fix in two places (front and back) with M10 nuts and bolts, through the lifting plates
- Fix in four places (two at the front and two at the back) with M6 nuts, bolts and washers.

When baying a master cubicle and a slave cubicle, the master must be located on the right.



Lifting plates M10 fastening (2 places)

- M10 flange headed set screw
- 2. M10 nut
- 3. Slave cubicle frame
- 4. Master cubicle frame



Frames M6 fastening (4 places)

- 1. M6 nut
- M6 star lock washer 2.
- 3. Slave cubicle frame:
- 4. Master cubicle frame
- 5. M6 screw





SCIGATE AUTOMATION (S) PTE LTD

No.1 Bukit Batok Street 22 #01-01 Singapore 659592 Tel: (65) 6561 0488 Email: sales@scigate.com.sg


Fax: (65) 6562 0588
Web: www.scigate.com.sg

Business Hours: Monday - Friday 8.30am - 6.15pm





Figure 1-4 Baying the size 9 master and slave




Master and slave cubicles bayed together

From the size 9 baying kit (6771-0025):

- 2. Fit the safety ground link: 6771-0029 (M10 nuts)
- 3. Fit the incomer EMC plate: 6771-0046 (M8 x 20 screws)
- 4. and 5. Fit the input parallel busbar: 6531-0222 (M8 x 20 screws); and M6 x 30 insulating spacer: 6262-0630 (M6 x 12 screws)
- 6. Fit the input parallel busbar: 6531-0222 (M8 x 20 screws)

Figure 1-5 Fitting parallel cable and rectifier status cable from a master to slave



- 1. Remove size 9 slave interface cover
- 3. Replace size 9 slave interface cover
- 5. Replace all size 9 cubicle panels


- 2. Connect the paralleling cable to the size 9 slave input slot
- 4. Ensure the rectifier status connectors are connected together. See Figure 1-2





0471-0061-02

Figure 1-6 Unidrive SP size 9 free standing cubicle drive power connections



*Cubicles are supplied without internal fuses as standard, the user must fit them during installation. Fuses may be bought from Control Techniques.

^{**}Cable shield must be bonded to gland plate.



